



Aritech Reliance XR Series Installation and Programming Guide

Copyright © 2023 Carrier Fire & Security

All rights reserved.

This document may not be copied in whole or in part or otherwise reproduced without prior written consent from Carrier Fire & Security, except where specifically permitted under US and international copyright law.

Trademarks and patents Aritech name and logo are trademarks of Carrier Fire & Security

IOS is the registered trademark of Cisco Technology, Inc.

Android, Google and Google Play are registered trademarks of Google Inc.

iPhone, Apple, iTunes are registered trademarks of Apple Inc.

App Store is a service mark of Apple Inc.

Other trade names used in this document may be trademarks or registered trademarks of the manufacturers or vendors of the respective products.

Manufacturer Placed on the market by:

Carrier Fire & Security

3211 Progress Drive, Lincolnton, NC, 28092, USA

Authorized EU manufacturing representative:

Carrier Fire & Security B.V.

Kelvinstraat 7, 6003 DH Weert, Netherlands

Warnings and Disclaimers These products are intended for sale to, and installation by, an experienced security professional. Carrier Fire & Security cannot provide any assurance that any person or entity buying its products, including any “authorized dealer,” is properly trained or experienced to correctly install security related products.

For more information on product warnings, refer to firesecurityproducts.com/policy/product-warning/ or scan the code.

Contact information For contact information, point of sale

Customer support For customer support in Australia, point of sale

Firmware version This manual was updated for firmware version A59P0000009-42

Contents

Aritech Reliance XR Series Installation and Programming Guide	1
Important information.....	vi
Limitation of liability	vi
Product Warnings	vi
Warranty Disclaimers.....	vii
Disclaimer	viii
Intended Use.....	viii
Advisory messages.....	viii
Introduction	9
System Capacity	9
Aritech Reliance XR Specifications.....	10
Product Codes.....	10
Mains power specifications	10
Power supply specifications.....	11
General features	12
Current Consumption	13
Output Current Rating	13
Environmental.....	13
Physical Dimensions and Weight.....	13
Fuses	14
Maintenance	14
System Monitoring	15
SIA and CID reporting code descriptions	15
End Of Line (EOL) Resistors.....	19
Aritech Reliance XR Pro Layout	20
Aritech Reliance XR Pro Wiring Diagram	20
Aritech Reliance XR Pro Terminals.....	21
Aritech Reliance XR Pro LEDs.....	22
Aritech Reliance XR Layout	23
Aritech Reliance XR Wiring Diagram.....	23
Aritech Reliance XR LEDs	25
Aritech Reliance XR Installation.....	26
Power Requirements	26
Cable Requirements.....	26
Shielding.....	26
Termination Links	26
Installing Panel.....	27
Installing Legacy NX Modules	27
Installing Antennas	28
Enrolling Modules	29
Deleting Modules.....	29

Defaulting Panel.....	30
Defaulting Installer Account	31
Getting Connected	32
Account Access.....	32
Method 1: UltraSync+ App.....	33
Method 2: Web Server.....	39
Method 3: DLX900 Management Software	42
Method 4: NXX-1820- Keypad.....	44
Programming with App / Web Server	45
Recommended Items to Change.....	45
Learning Wireless Zones	47
Adding a User	52
Adding a Keyfob	53
Advanced Keyfob Programming	54
Configuring Email Reports	56
Enabling Push Notifications on Smartphone	57
Reporting to a Control Room	62
DLX900 Software.....	64
Installing DLX900.....	64
Upgrading from DL900.....	64
Login to DLX	64
Navigating the Main Window	66
Customer Window	67
Navigating the Menus.....	68
Control Panel Menu	69
Loading Control Panel Defaults.....	69
Devices Menu.....	70
Device Info	71
Download Menu.....	72
Reading Data	72
Sending Data	73
Tools Menu	74
Programming with DLX900	75
Programming Instructions for System Options	75
Programming Instructions for Permissions.....	79
Programming Instructions for Menus.....	81
Programming Instructions for Holidays	83
Programming Instructions for Users.....	87
Programming Instructions for Zones	90
Programming Instructions for Custom Zones.....	93
Programming Instructions for Areas.....	96
Programming Instructions for Schedules.....	99
Programming Instructions for Arm-Disarm	103
Programming Instructions for Communicator	107
Programming Instructions for UltraSync	111

Programming Instructions for Event Lists	112
Programming Instructions for Channels	114
Programming Instructions for Zone Reporting.....	118
Programming Instructions for System Event Reporting	121
Programming Instructions for Actions.....	123
Programming Instructions for Action Groups	125
Programming Instructions for Scenes	127
Programming Instructions for Outputs	128
Combining Actions with Schedules.....	129
Arming and Disarming Your System	131
Lock Out On 3 Invalid Attempts.....	131
Arm Your System In Away Mode	131
Arm Your System In Stay Mode	131
Arm Your System in Instant Stay Mode	131
Arm Your System In Night Mode	132
Disarm One Or More Areas	132
Activate SOS Feature	132
Walk Test	133
User Reporting.....	133
Appendix 1: System Status Messages	134
Appendix 2: App and Web Error Messages	136
Appendix 3: Advanced Menu Tree.....	137
Appendix 4: Troubleshooting	138

Important information

Limitation of liability

To the maximum extent permitted by applicable law, in no event will Carrier be liable for any lost profits or business opportunities, loss of use, business interruption, loss of data, or any other indirect, special, incidental, or consequential damages under any theory of liability, whether based in contract, tort, negligence, product liability, or otherwise. Because some jurisdictions do not allow the exclusion or limitation of liability for consequential or incidental damages the preceding limitation may not apply to you. In any event the total liability of Carrier shall not exceed the purchase price of the product. The foregoing limitation will apply to the maximum extent permitted by applicable law, regardless of whether Carrier has been advised of the possibility of such damages and regardless of whether any remedy fails of its essential purpose.

Installation in accordance with this manual, applicable codes, and the instructions of the authority having jurisdiction is mandatory.

While every precaution has been taken during the preparation of this manual to ensure the accuracy of its contents, Carrier assumes no responsibility for errors or omissions.

Product Warnings

YOU UNDERSTAND THAT A PROPERLY INSTALLED AND MAINTAINED ALARM/SECURITY SYSTEM MAY ONLY REDUCE THE RISK OF EVENTS SUCH AS BURGLARY, ROBBERY, FIRE, OR SIMILAR EVENTS WITHOUT WARNING, BUT IT IS NOT INSURANCE OR A GUARANTEE THAT SUCH EVENTS WILL NOT OCCUR OR THAT THERE WILL BE NO DEATH, PERSONAL INJURY, AND/OR PROPERTY DAMAGE AS A RESULT.

THE ABILITY OF INTEROGIX'S PRODUCTS, SOFTWARE OR SERVICES TO WORK PROPERLY DEPENDS ON A NUMBER OF PRODUCTS AND SERVICES MADE AVAILABLE BY THIRD PARTIES OVER WHICH ARITECH HAS NO CONTROL AND FOR WHICH ARITECH SHALL NOT BE RESPONSIBLE INCLUDING, BUT NOT LIMITED TO, INTERNET, CELLULAR AND LANDLINE CONNECTIVITY; MOBILE DEVICE AND OPERATING SYSTEM COMPATIBILITY; MONITORING SERVICES; ELECTROMAGNETIC OR OTHER INTERFERENCE, AND PROPER INSTALLATION AND MAINTENANCE OF AUTHORIZED PRODUCTS (INCLUDING ALARM OR OTHER CONTROL PANEL AND SENSORS).

ANY PRODUCT, SOFTWARE, SERVICE OR OTHER OFFERING MANUFACTURED, SOLD OR LICENSED BY ARITECH, MAY BE HACKED, COMPROMISED AND/OR CIRCUMVENTED AND ARITECH MAKES NO REPRESENTATION, WARRANTY, COVENANT OR PROMISE THAT ITS PRODUCTS (INCLUDING SECURITY PRODUCTS), SOFTWARE, SERVICES OR OTHER OFFERINGS WILL NOT BE HACKED, COMPROMISED AND/OR CIRCUMVENTED.

ARITECH DOES NOT ENCRYPT COMMUNICATIONS BETWEEN ITS ALARM OR OTHER CONTROL PANELS AND THEIR WIRELESS OUTPUTS/INPUTS INCLUDING BUT NOT LIMITED TO, SENSORS OR DETECTORS UNLESS REQUIRED BY APPLICABLE LAW. AS A RESULT, THESE COMMUNICATIONS MAY BE INTERCEPTED AND COULD BE USED TO CIRCUMVENT YOUR ALARM/SECURITY SYSTEM.

THE EQUIPMENT SHOULD ONLY BE OPERATED WITH AN APPROVED POWER ADAPTER WITH INSULATED LIVE PINS.

DO NOT CONNECT TO A RECEPTACLE CONTROLLED BY A SWITCH.

THIS UNIT INCLUDES AN ALARM VERIFICATION FEATURE THAT WILL RESULT IN A DELAY OF THE SYSTEM ALARM SIGNAL FROM THE INDICATED CIRCUITS. THE TOTAL DELAY (CONTROL UNIT PLUS SMOKE DETECTORS) SHALL NOT EXCEED 60 SECONDS. NO OTHER SMOKE DETECTOR SHALL BE CONNECTED TO THESE CIRCUITS UNLESS APPROVED BY THE LOCAL AUTHORITY HAVING JURISDICTION.

WARNING: The equipment should only be operated with an approved power adapter with insulated live pins.

Caution: Risk of explosion if battery is replaced by an incorrect type. Dispose of batteries according to the instructions. Contact your supplier for replacement batteries.

Warranty Disclaimers

ARITECH HEREBY DISCLAIMS ALL WARRANTIES AND REPRESENTATIONS, WHETHER EXPRESS, IMPLIED, STATUTORY OR OTHERWISE, INCLUDING ANY IMPLIED WARRANTIES, THE WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

(USA only) SOME STATES DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO THE ABOVE EXCLUSION MAY NOT APPLY TO YOU. YOU MAY ALSO HAVE OTHER LEGAL RIGHTS THAT VARY FROM STATE TO STATE.

ARITECH DOES NOT MAKE ANY CLAIMS OR WARRANTIES TO YOU OF ANY KIND REGARDING ANY PRODUCT, SOFTWARE OR SERVICE'S POTENTIAL, ABILITY, OR EFFECTIVENESS TO DETECT, MINIMIZE, OR IN ANYWAY PREVENT DEATH, PERSONAL INJURY, PROPERTY DAMAGE, OR LOSS OF ANY KIND WHATSOEVER.

ARITECH DOES NOT REPRESENT TO YOU THAT ANY PRODUCT (INCLUDING SECURITY PRODUCTS), SOFTWARE, SERVICE OR OTHER OFFERING MAY NOT BE HACKED, COMPROMISED AND/OR CIRCUMVENTED.

ARITECH DOES NOT WARRANT THAT ANY PRODUCT (INCLUDING SECURITY PRODUCTS), SOFTWARE OR SERVICE MANUFACTURED, SOLD OR LICENSED BY ARITECH WILL PREVENT, OR IN ALL CASES PROVIDE ADEQUATE WARNING OF OR PROTECTION FROM, BREAK-INS, BURGLARY, ROBBERY, FIRE, OR OTHERWISE.

ARITECH DOES NOT WARRANT TO YOU THAT ITS SOFTWARE OR PRODUCTS WILL WORK PROPERLY IN ALL ENVIRONMENTS AND APPLICATIONS AND DOES NOT WARRANT ANY PRODUCTS AGAINST HARMFUL ELECTROMAGNETIC INTERFERENCE INDUCTION OR RADIATION (EMI, RFI, ETC.) EMITTED FROM EXTERNAL SOURCES

ARITECH DOES NOT PROVIDE MONITORING SERVICES FOR YOUR ALARM/SECURITY SYSTEM ("MONITORING SERVICES"). IF YOU ELECT TO HAVE MONITORING SERVICES YOU MUST OBTAIN SUCH SERVICE FROM A THIRD PARTY AND ARITECH MAKES NO REPRESENTATION OR WARRANTY WITH RESPECT TO SUCH SERVICES INCLUDING WHETHER OR NOT THEY WILL BE COMPATIBLE WITH THE PRODUCTS, SOFTWARE OR SERVICES MANUFACTURED, SOLD OR LICENSED BY ARITECH.

Disclaimer

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE. CARRIER ASSUMES NO RESPONSIBILITY FOR INACCURACIES OR OMISSIONS AND SPECIFICALLY DISCLAIMS ANY LIABILITIES, LOSSES, OR RISKS, PERSONAL OR OTHERWISE, INCURRED AS A CONSEQUENCE, DIRECTLY OR INDIRECTLY, OF THE USE OR APPLICATION OF ANY OF THE CONTENTS OF THIS DOCUMENT. FOR THE LATEST DOCUMENTATION, CONTACT YOUR LOCAL SUPPLIER OR VISIT US ONLINE AT WWW.UTCFIREANDSECURITY.COM.

This publication may contain examples of screen captures and reports used in daily operations. Examples may include fictitious names of individuals and companies. Any similarity to names and addresses of actual businesses or persons is entirely coincidental.

The illustrations in this manual are intended as a guide and may differ from your actual unit as Aritech Reliance XR is continually being improved.

Intended Use

Use this product only for the purpose it was designed for; refer to the data sheet and user documentation. For the latest product information, contact your local supplier or visit us online at www.utcfireandsecurity.com.

The system should be checked by a qualified technician at least every 3 years and the backup battery replaced as required.

Advisory messages

Advisory messages alert you to conditions or practices that can cause unwanted results. The advisory messages used in this document are shown and described below.

WARNING: Warning messages advise you of hazards that could result in injury or loss of life. They tell you which actions to take or to avoid preventing the injury or loss of life.

Caution: Caution messages advise you of possible equipment damage. They tell you which actions to take or to avoid preventing damage.

Note: Note messages advise you of the possible loss of time or effort. They describe how to avoid the loss. Notes are also used to point out important information that you should read

Introduction

The Aritech Reliance XR is an advanced intrusion panel with native IP reporting to UltraSync cloud. It has been designed for smartphone access to allow professional installer programming, and end-users' convenient access.

With large expansion capabilities, multi-area mode, wireless expansion, advanced user permissions, advanced schedules, and smart home features, the Aritech Reliance XR is suitable for residential and small commercial applications.

The system can be quickly programmed using drop-down menus in the UltraSync+ app. Programming is possible using a web browser or DLX900 desktop software.

All zones, areas, lists, groups, outputs, schedules, permission profiles, and defaults can be assigned a text name to make it easy to program and maintain.

When installed with the NXX-1820- touchscreen keypad, menus appear as plain text on a clear 3.5" screen with access to all programming features.

System Capacity

Feature	Aritech Reliance XR	Aritech Reliance XR Pro
On-board zones	4	8
Zone doubled	8	16
Wireless Zones	16	176
Wireless Receiver	63-bit and 80plus encrypted devices	63-bit and 80plus encrypted devices
Areas	4	8
Users	40	256
Max Keyfobs	8	16
Max Tablets	4	4
Max Expander Modules incl Keypads	32 Total [16 Keypads max]	32 Total [24 Keypads max]
IP Communicator	Built-in	Built-in
UltraSync+ app	Yes	Yes

Aritech Reliance XR Specifications

Product Codes

Product	Main description	Additional description
NXX-8-W-AU	Aritech Reliance XR Pro	Aritech Reliance XR Pro Panel /w 8 Hardwired Zones, 433/433MHz 80 Bit, Home Automation, metal housing, tamper switch
NXX-4-W-AU	Aritech Reliance XR	Aritech Reliance XR Panel /w 4 Hardwired Zones, 433/433MHz 80 Bit, metal housing, tamper switch
NXX-8-W-BO-AU	Aritech Reliance XR Pro, Board Only	Aritech Reliance XR Pro Panel /w 8 Hardwired Zones, 433/433MHz 80 Bit, 921.42MHz
NXX-4-W-BO-AU	Aritech Reliance XR, Board Only	Aritech Reliance XR Panel /w 4 Hardwired Zones, 433/433MHz 80 Bit, board only
NXX-4GWF	4G & WiFi Router Module	Dual SIM 4G cellular and WiFi router module
NXX-1820	Touchscreen Keypad	3.5" Touchscreen keypad, multilingual
RF-EV1016-K4	Wireless Mirror Optic PIR Two Way 80plus	
RF-4041-07-2	4-button Keyfob Two Way, 433Mhz 80plus	
RF-DC101-K4	Wireless Door Window Switch, 433MHz 80plus	
RF-1110-07-1	Micro Door Window Switch Two Way, 433MHz 80plus White	
RF-EV1012PI-K4	Wireless Mirror Optic Pet Immune PIR Two Way 80plus	
RF-7120-07-1	"Designer" Stand-alone Wireless Indoor Siren (800mAh)	
RF-7220-07-1	"Designer" Stand-alone Wireless Outdoor Siren	
BS7201-N	Lithium Battery for RF-7220-07-1	

Mains power specifications

Mains input voltage	230 Vac +10%, -15%, 50 Hz ±10%
Current consumption at 230 Vac	240 mA max.
Transformer output :	16.3 VAC 24 VA 16.3 VAC 48 VA

Power supply specifications

Power supply type	For indoor use inside the supervised premises
Power supply voltage	13.8 VDC +/- 0.4 V
Power supply current	2 A max. at 13.8 VDC +/- 0.4 V
Main board consumption	
Aritech Reliance XR Pro	130 mA at 13.8 VDC +/- 0.4 V
Aritech Reliance XR	130 mA at 13.8 VDC +/- 0.4 V
Maximum system current available	
Aritech Reliance XR Pro	2000 mA at 13.8 VDC +/- 0.4 V
Aritech Reliance XR	2000 mA at 13.8 VDC +/- 0.4 V
Auxiliary power output (AUX. POWER)	
Aritech Reliance XR Pro	13.8 VDC +/- 0.2 V, 1 A max.
Aritech Reliance XR	13.8 VDC +/- 0.2 V, 1 A max.
Battery power output (BAT)	
Aritech Reliance XR Pro	13.8 VDC +/- 0.2 V, 350 mA max.
Aritech Reliance XR	13.8 VDC +/- 0.2 V, 350 mA max.
Battery type	Lead acid rechargeable 7.2 Ah 12 V nominal
Minimum voltage	9.45 VDC
Maximum voltage at power supply, auxiliary power output and battery power output	14.5 VDC
Battery low condition	11.3 Vdc to 11.8 Vdc
Battery disconnect voltage	9.77 Vdc
Maximum ripple voltage V, p-p	200 mV typical, 400 mV max.

General features

Code combinations	From 10,000 (4 digits) to 100,000,000 (8 digits)
Aritech Reliance XR Pro	From 10,000 (4 digits) to 100,000,000 (8 digits)
Aritech Reliance XR	
Maximum user number:	
Aritech Reliance XR Pro	256
Aritech Reliance XR	40
User Permissions	128
Onboard zones	
Aritech Reliance XR Pro	8 (default); 16 if zone doubling enabled.
Aritech Reliance XR	4 (default); 8 if zone doubling enabled.
Maximum zone number:	
Aritech Reliance XR Pro	176
Aritech Reliance XR	24
Additional inputs	
Aritech Reliance XR Pro	1: box tamper
Aritech Reliance XR	1: box tamper
End-of-line resistor	820 Ω (2-wire smoke) 3.3 k Ω , 4.1 k Ω , 4.7 k Ω (alarm) 3.74 k Ω , 6.98 k Ω (zone doubling)
Onboard outputs:	
Aritech Reliance XR Pro	4 programmable outputs, bell, and smoke
Aritech Reliance XR	3 programmable outputs, and bell
Maximum output number	32
Maximum action number	256, main panel supports 32 actions, each output module adds 32 actions, seven output modules will provide a maximum of 256 actions
Areas:	
Aritech Reliance XR Pro	8
Aritech Reliance XR	4
Maximum keypad	
Aritech Reliance XR Pro	24
Aritech Reliance XR	16
Maximum expander modules (incl keypads and tablets)	32
Non-volatile Memory	
Event log capacity	1024
Data retention (log, program settings)	10 years
Ethernet connection (IP only)	
Supported standard	IEEE 802.3u
Speed	10BASE-T or 100BASE-TX
Duplex	Half-duplex and full-duplex
Cabling	FTP (foiled twisted pair) Cat 5e cable or better
Aritech Reliance XR bus	
Type	4 wire RS485 bus High common mode tolerance (25V)
Capacity	Up to 32 devices
Range	800m
Recommended Cable	Belden 7201A, 3107A, 9842, or exact equivalent 2 pair twisted shielded cable designed for RS485 (see "Cable Requirements" on page 26)

Current Consumption

Product	Main description	Current Consumption (non-alarm)	Current Consumption (alarm)
NXX-8-WZ-AU	Aritech Reliance XR Pro	130 mA typical	130 mA typical
NXX-4-W-AU	Aritech Reliance XR	130 mA typical	130 mA typical
NXX-1820	Touchscreen keypad	100 mA typical, 40 mA in idle mode	175 mA max with sounder and screen on max brightness

Output Current Rating

Aritech Reliance XR Pro / Aritech Reliance XR (AU)

Output	Total Max Output Current	
	24 VA Transformer	48 VA Transformer
Combined J2 BELL+, J2 AUX+ (Smoke), and J7 AUX+ (Outputs)	650 mA max at 13.8 VDC	1.6 A max at 13.8 VDC
Combined J2 POS (XR Bus), and J3 POS (NX Bus)		

Environmental

Operating temperature	-10 to +55°C
Humidity	95% non-condensing
IP protection grade	IP30

Physical Dimensions and Weight

Product	Main description	Dimensions (HxWxD)	Weight (g)
NXX-8-WZ-AU	Aritech Reliance XR Pro /w metal enclosure and tamper	292 x 291 x 91 mm (enclosure only) 437 x 291 x 91 mm (with antennas)	2075 g
NXX-4-W-AU	Aritech Reliance XR /w metal enclosure and tamper	214 x 232 x 94 mm (enclosure only) 359 x 232 x 94 mm (with antennas)	1435 g
NXX-8-WZ-BO-AU	Aritech Reliance XR Pro, board only	273 x 89 x 25 mm	210 g
NXX-4-W-BO-AU	Aritech Reliance XR, board only	192 x 89 x 25 mm	155 g
NXX-1820	Touchscreen keypad	18 x 82 x 125 mm	150 g

Fuses

Battery	4 A, resettable
12 V aux (combined for J2 BELL+, J2 AUX+, J7 AUX+)	3 A, resettable
System LAN (combined for J2 POS, J3 POS)	2 A, resettable

Maintenance

No regular maintenance needed. System will report servicing when necessary.

System Monitoring

The system provides monitoring for the following items.

Monitoring function	Message	Cause
AC Mains	Mains fail	Loss of external power supply [1]
Battery	Battery low	Battery low voltage [1]
	Battery test fail	Exhausted battery Battery charger fail
	Fuse/power output fail	Output overload
Power outputs	Fuse/power output fail	Exhausted fuse Fuse loss Short circuit Overload
Power supply	Power unit/power output fail	Power unit failure Overvoltage
Tampers	Device tamper	Device sabotage

SIA and CID reporting code descriptions





CID Code	Class	SIA Code	Event
E110	Alarm	FA	Fire alarm
R110	Alarm restore	FR	Fire alarm restore
E120	Alarm	PA	24 hour alarm
R120	Alarm restore	PR	24 hour alarm restore
E130	Alarm	BA	Burg alarm
R130	Alarm restore	BR	Burg alarm restore
E570	Bypass	B	Bypass
R570	Bypass	U	Bypass restore
E383	Zone tamper	TA	Tamper
R383	Zone tamper	TR	Tamper restore
E380	Trouble	T	Trouble
R380	Trouble	R	Trouble restore
E384	Sensor batt	XT	Sensor low battery
R384	Sensor batt	XR	Sensor low battery restore
E381	Sensor lost	S	Wireless supervision
R381	Sensor lost	R	Wireless supervision restore
E200	Sensor lost	SS	Fire supervision
R200	Sensor lost	SR	Fire supervision restore
E391	Sensor lost	NA	Zone activity supervision
R391	Sensor lost	NS	Zone activity supervision restore
E378	Alarm	BG	Cross zone initial trip
R378	Alarm	BR	Cross zone initial trip restore
E389	Sensor batt	AS	Fire maintenance alarm
R389	Sensor batt	AN	Fire maintenance alarm restore
E426	Access alarm	DL	Door propped

R426	Access alarm	DH	Door propped
E423	Access alarm	DF	Door forced
R423	Access alarm	DR	Door forced
E611	Test	TP	Start walk test zone
E389	Test	TE	End zone test
E611	Test	TP	Walk test zone passed
E389	Test	TE	Walk test zone failed
E383	Zone tamper	TA	Tamper
R383	Zone tamper	TR	
E139	Alarm	BA	
E130	Alarm	BV	
E129	Alarm	HA	
E120	Alarm	HV	
E129	Alarm	PA	
E120	Alarm	HV	
E115	Manual alarm	FA	Manual fire
E100	Manual alarm	MA	Manual medical
E123	Manual alarm	PA	Manual audible panic
E122	Manual alarm	HA	Manual silent panic
E124	Manual alarm	HA	Duress
E461	Tamper	JA	Keypad lockout
E137	Tamper	TA	Box tamper
R137	Tamper	TR	Box tamper restore
E301	Ac power	AT	Mains fail event
R301	Ac power	AR	Mains fail event restore
E302	Battery power	YT	Battery low event
R302	Battery power	YR	Battery low event restore
E312	Aux power	YI	Over current
R312	Aux power	YJ	Over current restore
E320	Siren trouble	YA	Siren tamper
R320	Siren trouble	YH	Siren tamper restore
E351	Telephone cut	LT	Telephone fault
R351	Telephone cut	LR	Telephone fault restore
E354	Comms fail	YC	Communication failure
R354	Comms fail	YK	Communication failure restore
E333	Expander trouble	ET	Device failure
R333	Expander trouble	ER	Device failure restore
E401	Open	OP	Open
R401	Open	CL	Close
E401	Open	OP	First open
R401	Open	CL	Last close
E451	Open	CG	Partial close
E374	Recent close	EE	Exit error
E459	Recent close	CR	Recent close
E406	Cancel	AB	Abort
E406	Cancel	OC	Cancel
E602	Automatic test	RP	Automatic test
E601	Test	RX	Manual test
E625	Local program	JT	Clock changed
E627	Local program	LB	Start local program

E628	Local program	LX	End local program
E627	Remote program	RB	Start remote program
E628	Remote program	RS	End remote program
E607	Test	TS	Start walk test mode
R607	Test	TE	End walk test mode
E466	Recent close		Technician arrival
R466	Recent close	YZ	Technician left
E310	System troubles	FT	Ground fault
R310	System troubles	FR	Ground fault restore
E606	Alarm	LF	Start listen in
R606	Alarm	LE	End listen in
E451	Open	OK	Early opening (disarmed before opening window)
R452	Open	CJ	Late closing (armed after the opening window)
E453	Open	OI	Fail to open
E454	Open	CI	Fail to close
E344	System troubles	XQ	Wireless jam
R344	System troubles	XH	Wireless jam restore
E414	System troubles		System shut down
R414	System troubles	RR	System turn on
E323	Access	RC	Output activated
R323	Access	RO	Output restored
E531	Expander trouble	SC	Device enrolled
E422	Access	DG	User activated output
E422	Access	DG	Door access
E421	Access	DV	Door access denied
E305	Comms fail	YW	Watchdog reset
R451	Open	OP	Partial open
E401	Abortable alarm	BC	Abort alarm
E102	Access	JK	Guard tour fail
E641	Test	NA	Activity monitor fail
E422	Access	DG	Valid code entered
E421	Access	DP	Valid code out schedule
E421	Access	DV	Valid code void
E421	Access	DV	Valid code lost
E421	Access	DV	Valid code expired
E628	Access	RU	Remote program fail
E102	Access	CL	Man down rearm
E305	Expander trouble	RR	Powerup
R305	Expander trouble	RR	Powerup restore
R601	Test	RX	Manual test restore
E452	Open	OJ	Late opening
R451	Open	CK	Early closing
E532	Device bypass	UB	Device bypass
E531	Device bypass	UU	Device unbypass
E304	Checksum fault	YF	Checksum failure
R304	Checksum fault	YG	Checksum failure restore
E338	Battery power	YT	Expander low battery
R338	Battery power	YR	Checksum failure restore
E337	Battery power	YT	DC fail
R337	Battery power	YR	DC fail restore

E609	Video		Video event
E351	Comms fail	LT	IP path fault
R351	Comms fail	LR	IP path fault restore
E458	Open		Geo fence 1 entered
R458	Open		Geo fence 1 exited
E458	Open		Geo fence 2 entered
R458	Open		Geo fence 3 exited
R351	System troubles	LR	Power supply fault
R351	System troubles	LR	Power supply fault restore

End Of Line (EOL) Resistors


NON-ZONEDOUBLE	ZONE DOUBLE
<p>ANYZONE TERMINAL TERMINAL ANYCOM</p>  <p>N.C. CONTACT WITH EOL RESISTOR</p>	<p>ZONE DOUBLING ONLY FUNCTIONSWITH AUTHORISED VERSIONS OF CONTROL PANEL FIRMWARE.</p> <p>ONLY ZONES 1 TO 4 CAN BE ZONE DOUBLED. ZONE DOUBLED CONFIGURATIONS CAN ONLY BE USED WITH NORMALLY CLOSED DEVICES</p>
<p>ANYZONE ANYCOM TERMINAL TERMINAL</p>  <p>N.O. CONTACT WITH EOL RESISTOR</p>	<p>ANYZONE ANYCOM TERMINAL TERMINAL</p>  <p>6.98K E.O.L. (5 - 8)</p> <p>3.74K E.O.L. (1 - 4)</p> <p>3.74K RESISTOR FOR ZONES 1-4 6.98K RESISTOR FOR ZONES 5-8</p>
<p>ANYZONE ANYCOM TERMINAL TERMINAL</p>  <p>ONE N.O. CONTACT & ONE N.C. CONTACT WITH EOL RESISTOR</p>	<p>ANYZONE ANYCOM TERMINAL TERMINAL</p>  <p>3.74K</p> <p>ZONE DOUBLED CONFIGURATION USED ASA FIRE ZONE...</p>
<p>ANYZONE ANYCOM TERMINAL TERMINAL</p>  <p>TAMPER CONTACT</p> <p>ZONE TAMPER EOL RESISTOR</p> <p>SUPPORTED EOL RES. 3.3K, 4.1K, 4.7K</p>	<p>3.74K</p>  <p>6.98K</p> 

Aritech Reliance XR Pro Terminals

Top to bottom:

- Antenna 1 – after the board is installed in the metal enclosure, insert the antenna with the corresponding icon.
- Antenna 2 – after the board is installed in the metal enclosure, insert the antenna with the corresponding icon.
- LAN-, LAN+, NEG, POS – terminals for Aritech Reliance XR RS485 bus.
- S1 LEARN – enrollment button, hold down for 3s to activate automatic device enrollment feature. Hold down while powering up to reset the "installer" account to master installer user type with 9713 PIN.
- TERM – term link for Aritech Reliance XR RS485 bus. A TERM link should be installed on the two furthest devices.
- EARTH, AC, AC – connect transformer (16VAC 1.5A) to terminals for power.
- - BLACK, + RED – connect leads to 12V Sealed Lead Acid backup battery.
- BELL+, BELL- – supervised output for connecting an external 12V siren or internal piezo screamer.
- DATA, COM, POS – NetworX 3-wire bus for legacy modules and keypads.
- SMOKE-, AUX+ – supports two or four wire smoke detectors, for 2-wire smoke detectors the panel will drop power to the SMOKE- terminal to perform smoke alarm verification.
- COM, AUX+ – terminal for aux power to zones.
- ZONE 1 to 8, COM – terminals to connect to zones. Supports single EOL, zone doubling, and dual EOL tamper monitoring.
- J14 – Ethernet WAN link header must be fitted if no communicator module is installed and must be removed to accommodate communicator module.
- J11 – terminal to connect communicator module to Aritech Reliance XR.
- Ethernet – connect Ethernet cable to RJ45 socket to provide internet connectivity to Aritech Reliance XR.
- J13 USBUP – 5-pin connector used to upgrade and program Aritech Reliance XR with USBUP tool.
- TAMPER – connect to panel box tamper.
- AUX+ – terminal for auxiliary power.
- OUTPUT 4 – open collector output switches to ground, follows “armed” state at default.
- OUTPUT 3 – open collector output switches to ground, follows “ready” state at default.
- OUTPUT 2 – open collector output switches to ground, follows “any alarm” at default.
- OUTPUT 1 – open collector output switches to ground, follows “any siren” at default.

Aritech Reliance XR Pro LEDs




Top to bottom:

- D5 RF – red LED blinks when message sent / received from a 63bit / 80plus transmitter.
 - D7 LAN – green LED is lit when connected to UltraSync, remains off when not connected to UltraSync.
 - D4 LEARN – red LED blinks slowly during auto enrollment, blinks quickly during manual enrollment.
 - D3 XR BUS – red LED blinks to indicate Aritech Reliance XR bus is available.
 - D1 ETHERNET – red LED is lit when Ethernet cable is connected to WAN port, blinks when data is sent or received, and is off when cable is disconnected or J14 connector is removed.
- If 4G / WiFi router module is installed, LED is lit when panel has established connection to the module, and blinks when panel is communicating with the module.
- Check “Connection Status” web page to verify connection to UltraSync.

Aritech Reliance XR Layout

Aritech Reliance XR Wiring Diagram




Aritech Reliance XR Terminals

Top to bottom:

- Antenna 1 – after the board is installed in the metal enclosure, insert the antenna with the corresponding icon.
- Antenna 2 – after the board is installed in the metal enclosure, insert the antenna with the corresponding icon.
- LAN-, LAN+, NEG, POS – terminals for Aritech Reliance XR RS485 bus.
- S1 LEARN – enrollment button, hold down for 3s to activate automatic device enrollment feature. Hold down while powering up to reset the "installer" account to master installer user type with 9713 PIN.
- TERM – term link for Aritech Reliance XR RS485 bus. A TERM link should be installed on the two furthest devices.
- AC, AC, EARTH – connect transformer (16VAC 1.5A) to terminals for power.
- OUTPUT 3- – open collector output switches to ground, follows “ready” state at default.
- - BLACK, + RED – connect leads to 12V Sealed Lead Acid backup battery.
- AUX+, BELL- – supervised output for connecting an external 12V siren or internal piezo screamer.
- OUTPUT 2- – open collector output switches to ground, follows “any alarm” action at default.
- OUTPUT 1- – open collector output switches to ground, follows “any siren” action at default.
- DATA, COM, POS – NetworX 3-wire bus for legacy modules and keypads.
- ZONE 1 to 4, COM – terminals to connect to zones. Supports single EOL, zone doubling, and dual EOL tamper monitoring.
- J14 – Ethernet WAN link header must be fitted if no communicator module is installed and must be removed to accommodate communicator module.
- Ethernet – connect Ethernet cable to RJ45 socket to provide internet connectivity to Aritech Reliance XR.
- J13 USBUP – 5-pin connector used to upgrade and program Aritech Reliance XR with USBUP tool.
- TAMPER – connect to panel box tamper.
- J11 – terminal to connect communicator module to Aritech Reliance XR.

Aritech Reliance XR LEDs



Top to bottom:

- D5 RF – red LED blinks when message sent / received from a 63bit / 80plus transmitter.
- D7 ULTRASYNC LAN – green LED is lit when connected to UltraSync, remains off when not connected to UltraSync.
- D4 LEARN – red LED blinks slowly during auto enrollment, blinks quickly during manual enrollment.
- D3 XR BUS – red LED blinks to indicate Aritech Reliance XR bus is available.
- D1 ETHERNET – red LED is lit when Ethernet cable is connected to WAN port, blinks when data is sent or received, and is off when cable is disconnected or J14 connector is removed.

If 4G / WiFi router module is installed, LED is lit when panel has established connection to the module, and blinks when panel is communicating with the module.

Check “Connection Status” web page to verify connection to UltraSync.

Aritech Reliance XR Installation

Power Requirements

The Aritech Reliance XR range of products are to be only powered from an approved Australian power unit source.

The Aritech Reliance XR is designed to be used with a 16 VAC 1.5 Amp 24 VA transformer which is included with Aritech Reliance XR panel kits. If more current is required, upgrade to a 16 VAC 3 Amp 48 VA transformer and/or add NXG-320 Smart Bus Power Supplies.

Cable Requirements

The system RS-485 communication bus is used to connect keypads, input, and output expanders to the Aritech Reliance XR.

- Only VW-1 rated cable is to be used for installation of these products.
- 800 m total cable run on system.
- Max. 800 m from remote device to Aritech Reliance XR control panel.
- Max. 32 devices plus panel.

Shielding


The shielding of all shielded cables used in the system should only be connected at one side to one common earthing point in a building. If a shielded LAN cable is routed via more than one plastic device, the shielding from incoming and outgoing cable must be connected.

Termination Links

Put a jumper across TERM on the **panel and the furthest device** to ensure correct RS-485 termination and avoid communication issues with signal reflection, etc.

Installing Panel

1. The Aritech Reliance XR should be located away from damp areas (e.g. bathrooms, kitchens), away from sources of heat, dust or interference (e.g. air conditioners, washing machines, dryers, refrigerators) and away from external walls.
2. The metal enclosure should be installed with the door opening from the top to bottom.




3. Guides are cut into the enclosure to hold the panel, two on the top and two on the bottom. Two plastic brackets are pre-installed on the Aritech Reliance XR. Slide the panel into the guides as shown in the diagram. The terminal strip should face towards you once installed.

4. A plastic strap is provided to allow the door to form a temporary surface to hold light parts.

Installing Legacy NX Modules

Inside the enclosure there are several 2-holed insertion points. These allow for either vertical or horizontal placement of legacy NX modules. Each insertion point has a larger hole and a smaller hole.



1. The black plastic PCB guides feature a groove to hold an expansion module. The end with the half-moon protrusion fits into the larger hole. The smaller hole is for the screw.

2. Place the first black plastic PCB guide in the top insertion point, groove facing downward. The half-moon protrusion will be in the large hole. It does not require force to insert. Insert one of the provided screws into the smaller hole (from inside the enclosure) to secure it in place. A screwdriver should reach through the groove that runs the length of the guide to tighten the screw. The second PCB guide should be positioned opposite the first (groove facing up) and placed in the lower insertion point, using the same procedures described above. Once mounted, screw it in securely.


3. The NX module should slide freely in the grooves of both guides.

Installing Antennas

Several antennas may be provided depending on the model purchased. These include:


- Multi-antennas for ITI 63-bit, ITI 80plus.
- 3G/4G antennas for WiFi/cellular module
- WiFi antennas for WiFi/cellular module

Wireless Sensor Antennas



If two antennas have been provided:

1. Install panel into metal enclosure.
2. Install antennas vertically for best performance.
3. Each antenna is keyed (shaped differently) and labelled. Antennas are reasonably flexible but do not apply excessive force. Match the antenna to the shape molded on the plastic bracket and push to insert.
4. The line printed on each antenna will disappear when fully inserted.
5. Remove antennas before attempting to remove panel.
6. Antennas can be tampered monitored by enabling Advanced – General Options – Antenna Tamper.



4G Cellular and WiFi Router Module Antennas

If the optional 4G Cellular and WiFi Router Module has been installed, a single set of antennas should be connected to “MAIN” on the module. The antennas should be installed vertically, and as high up as possible.

The module includes MIMO wireless technology to improve reception of 3G/4G and WiFi wireless signals. This requires the installation of a second set of antennas to “DIV” on the 4G/WiFi Router Module. The second set of antennas will perform best when separated from the MAIN antennas by at least 20cm.

Enrolling Modules

New devices such as zone expanders, wireless zone expanders, output expanders, smart power supplies, and keypads need to be enrolled so they can be programmed and supervised.

The enrollment procedure discovers the serial number of the new device and adds it to the device database in the panel.

To enroll a module:

1. Press and hold the LEARN button until the LED next to the button blinks, then release button.
2. The panel is now in automatic enrollment mode and will search for new devices.
3. The D5 LED will stop blinking to indicate enrollment mode is finished.
4. Proceed to programming the system and the additional devices.

Enrollment can also be initiated:

- Using the NXX-1820 keypad: press Menu – [Installer PIN] – [ENTER] – Program – Devices – System Devices – Control – Enroll Function – 0 = Inactive – Automatic Enroll.
- Using the Aritech Reliance XR Web Server: click the Advanced Menu, click Devices – System – Control – Enroll Function – Automatic Enroll – Save.
- Using DLX900: click Devices – Device Info – Auto Enroll.

Deleting Modules

Devices such as zone expanders, output expanders, and keypads can be removed from the system by deleting the serial number from the device database.

To delete a module:

1. On the keypad press Menu – [Installer PIN] – [ENTER] – Program – Devices.
2. This menu will be displayed:
 1. System Devices
 1. Control
 2. Keypad
 3. Zone Exp
 4. Output Exp
 5. Power Supply
 2. ARITECH Transmitters
 1. Transmitter Number
 2. Serial Number

3. User
4. Options
5. Scene
3. Tablet Keypads
 1. Name
 2. Serial Number
 3. Area Group
 4. Keypad Options

3. Select the category and type. For example, to remove a keypad touch System Devices - Keypad.
4. Touch Device UID (Serial).
5. Touch the serial number displayed.
6. Touch Clear.
7. Touch OK.
8. The device has now been removed.

Deleting devices can also be done:

- Using the Aritech Reliance XR Web Server: click the Advanced Menu, click Devices, find the device to be removed, delete the serial number, click Save.
- Using DLX900: click Devices – Device Info, select the device, then click “Remove Device”.

Defaulting Panel

Panel can be reset to factory settings by performing the steps below. This will delete all programming including enrolled devices, users, and panel settings. An authorized installer PIN is required.

Panel can be defaulted using an NXG-1820 keypad:

1. Tap MENU.
2. Enter installer PIN.
3. Tap Program.
4. Tap Default.
5. Tap All.

Alternatively, from the web server:

1. Log in to the web server as installer.
2. Click Advanced.
3. Click Shortcut.
4. Enter **910.910**
5. Press OK.
6. Log out of panel

DLX900 can load default configuration if it can connect to the panel (requires valid download access code).

1. Open DLX900.
2. Connect to the desired panel.
3. Click Control Panel – Default control data from – Factory defaults.
4. Click Yes – all exiting programming for currently selected customer will be replaced with factory settings.
5. Click Send All Data.
6. Before disconnecting ensure Download Access Code, Web Access Code, and Installer PIN are set. Otherwise, you may not be able to reconnect.

Defaulting Installer Account

The installer PIN can be reset to factory default if physical access is available:

1. Disconnect power.
2. Hold down the LEARN button on the panel.
3. Connect power.
4. Continue holding the LEARN button for 10 seconds.
5. Release LEARN button.
6. Installer PIN will be reset to factory default.

Getting Connected


Once your devices have been cabled and installed, there are four (4) ways to connect to the Aritech Reliance XR system to perform programming:



Method 1: via UltraSync+ app – this provides access to the built-in Web Server via a smartphone app.



Method 2: via built-in Web Server – All features can be accessed from a web browser via drop-down and click-through menus. No software installation is required. This allows access to most accessed features for basic programming.



Method 3: via DLX900 Management Software – All features can be programmed using a PC with Microsoft Windows 7, 8 and 10. DLX900 allows easier programming of complex sites as the graphical interface can show all options from multiple menus simultaneously.



Method 4: via on-site keypad - The NXX-1820- touchscreen offers a programming menu for full system configuration. Refer to the NXX-1820- Installation Manual. The Aritech Reliance XR Reference Guide will assist you in navigating the menus.

Account Access

Note: Installer Account Disabled When Armed


If a non-engineer account arms the system at any time, engineer accounts will not be able to log in, any current program mode will end, and this will be recorded in the event log. Ask the end-user to disarm the panel and leave it disarmed so you can log in to program it.

Note: Remote Access May Require Level 2 User Authorization

Two remote access features “Enable Web Program” and “Always Allow DLX900” require an authorized master (Level 2) user to enter their PIN code on an NXX-1820- keypad before remote programming can be performed.

If either “Enable Web Program” or “Always Allow DLX900” have been **disabled**, ask a Master User to press Menu, enter their PIN code on a keypad, then Settings. The panel will now be in Program Mode, and you can use an engineer (Level 3) user such as “installer” to perform programming via the web page, app, or DLX900.

Method 1: UltraSync+ App



UltraSync+ is a smartphone app that allows you to:

- Check the status of your system
- Arm and Disarm areas
- Bypass zones
- Manage users
- Perform system programming

Access from the app is disabled by default for security. To allow access these settings must be enabled on your Aritech Reliance XR system:

- Web Access Code
It permits remote access from the UltraSync+ app. Set it to 00000000 to prevent the app from connecting.
- Username and PIN code
The UltraSync+ app requires any username and PIN code to log in to the system and display features available to that user.

Set Web Access Code and change installer PIN code

To enable the UltraSync+ app:

1. On the NXX-1820- keypad press Menu – [PIN] – [ENTER] – Program – scroll down to UltraSync – Web Access Passcode.
2. Enter a new 8-digit Web Access Passcode.

Change installer PIN code:

1. On the NXX-1820- keypad press Menu – [PIN] – [ENTER] – Users – Add. Modify
2. Enter a new PIN code.

Connect to Aritech Reliance XR via UltraSync+ app

UltraSync+ is an app that allows you to control your Aritech Reliance XR system from an Apple® iPhone/iPad, or Google Android device. First set up the Aritech Reliance XR Web Server then download this app. Carrier charges may apply and an Apple iTunes or Google account is required.



1. On your smartphone go to the Apple® App Store™ or Google Play™ store.



2. Search for UltraSync.
3. Install the app.
4. Click the icon on your device to launch it.
5. Click + on the top right to add a new site, or the (i) icon to edit an existing site.
6. Enter the details of your security system.
 - Locate the 12-digit serial number barcode on the Aritech Reliance XR circuit board. Alternatively log in to Aritech Reliance XR Web Server and go to Settings – Details to view it.
 - The default Web Access Passcode of 00000000 disables remote access. To change it, log in to Aritech Reliance XR Web Server and go to Settings - Network.
 - The default username and PIN code is "installer" 9713 (for an installer) and "User 1" 1234 (for a user). Please note that there is a space between "User" and "1". Username is case-sensitive. You may also use any other valid user account. Only menus a user has access to will be displayed.
7. Click Done button to save the details, then Sites to go back.
8. Click the name of the Site, the app will now connect you to Aritech Reliance XR.


Using the App

The first screen that will appear once you connect is the Overview screen. This will display the status of your system and allows you to arm or disarm areas by touching Arm Away, Arm Stay, or Disarm. It also allows you to activate programmed automation scenes.




The menu bar is located along the bottom of the app. Touch the Zones icon (last icon with a dot and wireless signals) to view zone status.

- Touch Bypass to ignore a zone or touch it again to restore it to normal operation.
- Touch Chime to add or remove a zone from the Chime feature.
- Touch Notify to receive push notifications when there is activity from that zone.




** Touch the Camera icon to view cameras connected to your system.

- Live snapshots from each camera will be shown. Touch the snapshot to open the live stream in full screen. Rotate your device to make the image bigger. Touch the screen then Back to return to the Camera screen.
- Touch the Play button under each camera to view the last recorded clip by that camera. Touch the Share button to save or forward the clip.
- Touch the Record button to request that camera record a short clip which can be retrieved later.




Video clips can also be accessed from the History screen. Touch Menu , HISTORY, then change Selected Events to Video. Touch “Press to Play Video” to retrieve the clip from the camera. Once downloaded, you can save or forward the clip.




This History screen displays the event log of the Aritech Reliance XR, recording important events and allowing authorized users the ability to audit the system. Changing the Selected Events to Alarms will display the filtered Mandatory Event Log.

Events followed with an * have not yet been reported to a control room or have failed to report. Events followed with ** are for events not intending to be reported to a control room.

Master users will have access to the full Users menu for creating and managing users. Touch Menu , USERS. Change User Type to Custom to show additional options.



When you log in with the installer account you will have access to the ADVANCED menus for setting up and programming the Aritech Reliance XR. Refer to the Aritech Reliance XR Reference Guide for additional help on the Advanced screen.



Troubleshooting

If you have trouble connecting to your system using the app, here is a checklist:

- Check the serial number, web access passcode, user name and PIN codes match those in the Aritech Reliance XR.
- Web Access Passcode must not be 00000000.
- Web Access Passcode must be from 4 to 8 digits.
- Username must be entered with a space between the first and last name and with correct capitalization.
- Check the Username does not have an extra space at the end.
- If connected by Wired LAN, check the cable is plugged in and that the connection is working.
- Check Settings – Network – Enable UltraSync is ticked.
- Check that your mobile device has access to the internet (e.g. open a web browser).
- Check the UltraSync servers are correct under Advanced – UltraSync:
 - Ethernet Server 1 - xg1.ultraconnect.com:443
 - Ethernet Server 2 - xg1.zerowire.com:443
 - Wireless Server 1 - xg1w.ultraconnect.com:8081
 - Wireless Server 2 - xg1w.zerowire.com:8081
- Power cycle connected equipment including Aritech Reliance XR and customer supplied router(s)


Method 2: Web Server

Aritech Reliance XR has a built-in web server which makes it easier to program using a web browser instead of a keypad. Features include:

- Simple forms to set up commonly used features
- View system and zone status
- Arm and disarm areas
- Bypass/Un-bypass zones
- Turn chime mode on and off
- Add, delete, and edit users
- Access to the advanced programming menu


Connect to Aritech Reliance XR Web Server over LAN

1. Turn on power to your system.
2. Connect an Ethernet cable to an available port on a router. Ideally this router has access to the Internet.
3. Connect the other end of the Ethernet cable to the J13 Ethernet port on the Aritech Reliance XR. Wait 10 seconds for the router to assign the Aritech Reliance XR an IP address if DHCP is available.
4. On the keypad press Menu – [PIN] – [ENTER] – Installer – Communicator – IP Configuration – IP Address and note the IP address displayed.
5. Connect your device to the same network (e.g., via WiFi or Ethernet cable).
6. Open a web browser
7. Enter the IP address from step 3 and the Aritech Reliance XR login screen should appear. Some browsers may require you to enter **http://**



The image shows a web browser login screen for the Aritech Reliance XR. It features a light gray background with the text "Sign In:" in bold. Below this, there are two input fields: "Enter Your Name:" followed by a white text box, and "Enter Your Password:" followed by a white text box. At the bottom of the form is a blue button with the text "Sign In" in white.

8. Enter your username and password, by default this is **installer** and **9713**.
9. You should now see a screen similar to:



Troubleshooting

If you are unable to get an IP address in step 3, then your router may not be configured for automatic DHCP or certain security settings may be enabled.


- Check your router settings and try again.
- On an NXX-1820- touchscreen keypad press Menu – [PIN] – [ENTER] – Installer – Communicator – IP Configuration – IP Options. “Enable DHCP” should be ticked, “Disable Web Pages on LAN” should be unticked.

Check LAN Connection to UltraSync

UltraSync is a cloud-based service that allows remote management and remote access to a Aritech Reliance XR system if enabled. This includes secure connections between the UltraSync+ app and Aritech Reliance XR. No programming, email addresses, panel usernames, or PIN codes are stored on the cloud servers for greater security.

It features full redundancy to route encrypted alarm messages from your panel to a Central Monitoring Station.

1. Log in to the Web Server as shown above
2. Click Settings
3. Select Connection Status in the drop-down menu
4. Check:
 - LAN Status should display “Connected”
 - UltraSync Status should display “Connected”
 - UltraSync Media should display “LAN” for single path Ethernet and dual-path systems
 - UltraSync Media should display “Cellular” for single-path cellular systems



If it does not:

1. Check cable connections.
2. Check router settings allow Internet access to LAN devices.
3. On the NXX-1820- touchscreen keypad press Menu – [PIN] – [ENTER] – Installer – Communicator – IP Configuration – IP Options. “Enable UltraSync” should be ticked.

Connect to Aritech Reliance XR via 4G Cellular and WiFi Router Module

An optional 4G Cellular and WiFi Router Module provides dual path reporting over WiFi/Ethernet and 4G. If the primary path (WiFi/Ethernet) is not working, the module will switch to 4G back-up reporting path to the central monitoring station. Multiple cellular networks are supported using dual-SIM cards for further redundancy.

Alternatively, the module can be set by the central monitoring station to use 4G single path reporting. This is useful for sites with no broadband internet.

The module is pre-configured. Once installed on the Aritech Reliance XR panel, it will automatically register on available mobile network(s). Refer to the 4G Cellular and WiFi Router Module manual for further details.

Check 4G connection to UltraSync

1. Log in to the Web Server as shown above.
2. Click Settings.
3. Select Connection Status in the drop-down menu.
4. Check:
 - UltraSync Status should display “Connected”.
 - Cell Service should display “Valid service”.

- Signal Strength should display a value. Check your cellular radio manual for acceptable values.

If it does not, check the 4G connection:

1. Check Settings – Network – Enable UltraSync is checked.

Alternatively, from a keypad press MENU – Program – Communicator – IP Configuration – IP Options – Enable UltraSync: Y.

2. Look at Cell State, it should display “Connected”. Please wait until Cell State displays “Connected”, click Reload to refresh the status.
3. Signal level should be between -89 to -51.
4. Check module is correctly installed.
5. Check antennas are correctly installed, move antennas to a higher location, install additional antennas to activate MIMO feature, or install high gain antenna(s).
6. Contact your service provider to check the SIM card is active and that cellular reporting is enabled for your unit on the UltraSync Portal.

Congratulations, your Aritech Reliance XR system is connected to your network and UltraSync. It is now ready to be programmed. Refer to Programming Guide starting on page 45.

Method 3: DLX900 Management Software

DLX900 is PC-based software tool for programming Aritech Reliance XR panels. It requires Microsoft Windows 7, 8, or 10 (recommended). It features a graphical interface, allowing installers and Central Monitoring Stations to program and manage complex sites. Customer details and all panel programming is stored in a local database.

For help installing or using DLX900, please read the section “DLX900 Software” starting on page 64.

DLX900 supports a variety of connection methods:

1. Local connection over LAN (an Ethernet router is required).
2. Remote connection over UltraSync (panel may be on Ethernet, WiFi, or cellular).
3. Remote connection over dial up PSTN (for legacy NX panels).

Connect to Aritech Reliance XR using DLX900 on LAN

1. Turn on power to your system.
2. Connect an Ethernet cable to the J13 Ethernet port on the Aritech Reliance XR and wait 10 seconds for the local router to assign the Aritech Reliance XR an IP address if DHCP is available.
3. On the keypad press Menu – [PIN] – [ENTER] – Installer – Communicator – IP Configuration – IP Address and note the IP address displayed.
4. Install DLX900 on a suitable computer.
5. Start DLX900.
6. Create a new customer.
7. Enter the IP address of your system.
8. Click Save.
9. Click Connect via TCP/IP.
10. Click Read All.
11. Refer to “Programming with DLX900” starting on page 75.

Connect to Aritech Reliance XR using DLX900 on UltraSync

The Download Access Passcode (under Communicator\Remote Access menu) and Always Allow DLX (under Communicator\IP Configuration\IP Options) must be enabled to allow DLX900 to connect.

1. Install DLX900 on a suitable computer, refer to DLX900 installation instructions.
2. Start DLX900.
3. Create a new customer.
4. Enter the serial number, Download Access Passcode and Web Access Passcode of the system.
5. Click Save.
6. Click Connect via TCP/IP.
7. Click Read All.
8. Refer to “Programming with DLX900” starting on page 75.

Method 4: NXX-1820- Keypad

The NXX-1820- is able to access all panel programming features with a valid installer code.

1. Press Menu – [Installer PIN] – [ENTER] – Program.
2. Scroll through the menus using the up and down buttons. Refer to Appendix 3: Advanced Menu Tree on page 137.
3. Press an item to go down a level or to select an option. Press the back arrow to go up a level or to cancel without saving.
4. Repeatedly press the back arrow to return to the main menu.

Note on legacy devices: NetworX keypads (including NX-1820) have limited access to Aritech Reliance XR programming. Aritech Reliance XR keypads (NXX-1820 and 7” Touch Screen) can program legacy NetworX devices via the Advanced – Devices menu.

Programming with App / Web Server

Most commonly used features can be programmed from the UltraSync+ app by logging into the site and clicking Menu - Settings.

The same menus are displayed from the Aritech Reliance XR Web Server under the Settings menu.

See the previous section on “Getting Connected” for help setting up the App or accessing the Web Server.

Recommended Items to Change

- **Installer Code.** This is the master key to most features. Always change this to prevent accidental modifications by end-users and unauthorized access to the security system.
- **User 1 PIN code** is 1234 at default. Always change this to prevent unauthorized access to the security system.
- **User 1 username** is “User 1” at default, there is a space between “User” and “1”. Usernames are required to provide access to the Aritech Reliance XR Web Server and UltraSync+ app.

- **Web Access Passcode.** This provides access to the Aritech Reliance XR Web Server, UltraSync, and UltraSync+ app. Log in to the Web Server and go to Settings – Network – Web Access Passcode.
- **DLX900 access** for upload/download is allowed if the panel is at factory default with the installer account set to PIN 9713. This is a convenience feature to allow the installer to connect to the panel for the first time and perform a Send All to program the panel. Once the installer PIN is changed, the Download Access Passcode of 00000000 disallows

DLX900 access. Log in to the Web Server and go to Settings – Network – Download Access Code.

The screenshot shows the DLX900 web interface. On the left is a navigation menu with the following items: Logout, Arm/Disarm, Zones, Cameras, History, Users, Settings (highlighted), and Advanced. The main content area is titled 'Settings Selector' and has a dropdown menu set to 'Network' and a 'Save' button. Below this is the 'LAN configuration' section, which includes an 'IP Host Name' field, an 'Enable DHCP' checkbox (checked), and a table for IP Address, Gateway, Subnet, Primary DNS, and Secondary DNS. The table data is as follows:

IP Address	192	168	1	222
Gateway	192	168	1	1
Subnet	255	255	255	0
Primary DNS	192	168	1	1
Secondary DNS	0	0	0	0


Below the LAN configuration is the 'Remote Access PIN' section, which includes a 'Web Access Passcode' field (circled in red) with the value '00000000', a 'Download Access Code' field (circled in red) with the value '00000000', an 'Automation User Name' field, and an 'Automation PIN' field with the value '00000000'. At the bottom is the 'Options' section with the following settings:

Enable Ping	<input checked="" type="checkbox"/>
Enable UltraSync	<input checked="" type="checkbox"/>
Monitor LAN	<input type="checkbox"/>
Always Allow DLX900	<input checked="" type="checkbox"/>
Enable Web Program	<input checked="" type="checkbox"/>

- If reporting to a control room via UltraSync, set Channel 1 to send events to UltraSync. Log in to the Web Server and go to Settings – Channels – Channel 1 – Format – UltraSync.



Learning Wireless Zones

1. Log in to the Web Server.



The image shows a 'Sign in' form with a title 'Sign in' in bold. Below the title, there are two input fields. The first is labeled 'Enter your username:' and contains the text 'installer'. The second is labeled 'Enter your password:' and contains four black dots. Below the password field is a blue button with the text 'Sign In'.

2. Enter your username and password, by default this is “installer” and “9713”, then click Sign In.
3. You should now see a screen similar to the one shown below.



4. Click Settings.
5. Click Zones.

6. Click Learn:

The screenshot displays a web interface for configuring zones. On the left is a vertical navigation menu with the following items: Logout, Arm/Disarm, Zones, Cameras, History, Users, Settings (highlighted in a dark grey bar), and Advanced. The main content area is titled 'Settings Selector' and features a 'Zones' dropdown menu at the top, followed by 'Up', 'Down', and 'Save' buttons. Below this is a section titled 'Zone Add/Remove Functions' containing three buttons: 'Learn' (circled in red), 'Remove', and 'Cancel'. The bottom section, 'Select Zone to Configure:', includes several fields: a dropdown for '1 Zone', an empty 'Zone Name' text box, a 'Zone Type' dropdown set to '3 Entry Exit Delay 1', a 'Zone Options' dropdown set to '1 Bypass', a 'Partition Group' dropdown set to '1 Partition 1', a 'Serial Number' text box containing '0', and a 'Tamper' checkbox which is currently unchecked.

7. Activate the zone. Consult the detector manual for instructions, generally this is performed by opening the detector's case. This will send a tamper signal to Aritech Reliance XR.
8. The screen will indicate the device has been learnt and a serial number will appear.
9. Customize zone settings if required by referring to the Zone Guide, Zone Profile Type Guide, and Zone Options Guide on the following pages.

Zone Types Table

Default Number	Default Name	Zone Attribute	Siren Attribute	Keypad Sounder	Report Delay	No Keypad Display	Momentary Switch	Zone Inhibit	Swinger Shutdown
Armed									
1	Day Zone	Instant	Yelping	Y	Y	N	N	N	Y
2	24 Hour Audible	Instant	Yelping	Y	Y	N	N	N	Y
3	Entry Exit Delay 1	Entry 1	Yelping	Y	Y	N	N	N	Y
4	Entry Exit Delay 2	Entry 2	Yelping	Y	Y	N	N	N	Y
5	Follower	Handover	Yelping	Y	Y	N	N	N	Y
6	Instant	Instant	Yelping	Y	Y	N	N	N	Y
7	24 Hour Silent	Instant	Silent	N	Y	N	N	N	Y
8	Fire Alarm	Fire	Fire	Y	N	N	N	N	N
9	Entry Exit Delay 1 Auto-Bypass	Entry 1	Yelping	Y	Y	N	N	Y	Y
10	Entry Exit Delay 2 Auto-Bypass	Entry 2	Yelping	Y	Y	N	N	Y	Y
11	Instant Auto-Bypass	Instant	Yelping	Y	Y	N	N	Y	Y
12	Event Only	Event Only	Silent	N	N	Y	N	N	N
13	Momentary Key Switch	Keyswitch	Silent	N	N	N	Y	N	N
14	Latching Key Switch	Keyswitch	Silent	N	N	N	N	N	N
15	CO Detector	Instant	Four Pulse	Y	N	N	N	N	N
16	Exit Terminate	Exit Terminate	Silent	N	N	N	N	N	N
17	Holdup	Holdup Delay	Silent	N	N	N	N	N	N
18	24 Hour Local Sounder	Instant	Silent	Y	N	N	N	N	N
Disarmed									
1	Day Zone	Local	Silent	Y	N	N	N	N	N
2	24 Hour Audible	Instant	Yelping	Y	Y	N	N	N	Y
3	Entry Exit Delay 1	Event Only	Silent	N	N	N	N	N	N
4	Entry Exit Delay 2	Event Only	Silent	N	N	N	N	N	N
5	Follower	Event Only	Silent	N	N	N	N	N	N
6	Instant	Event Only	Silent	N	N	N	N	N	N
7	24 Hour Silent	Instant	Silent	N	Y	N	N	N	Y
8	Fire Alarm	Fire	Fire	Y	N	N	N	N	N

Default Number	Default Name	Zone Attribute	Siren Attribute	Keypad Sounder	Report Delay	No Keypad Display	Momentary Switch	Zone Inhibit	Swinger Shutdown
9	Entry Exit Delay 1 Auto-Bypass	Event Only	Silent	N	N	N	N	N	N
10	Entry Exit Delay 2 Auto-Bypass	Event Only	Silent	N	N	N	N	N	N
11	Instant Auto-Bypass	Event Only	Silent	N	N	N	N	N	N
12	Event Only	Event Only	Silent	N	N	Y	N	N	N
13	Momentary Key Switch	Keyswitch	Silent	N	N	N	Y	N	N
14	Latching Key Switch	Keyswitch	Silent	N	N	N	N	N	N
15	CO Detector	Instant	Four Pulse	Y	N	N	N	N	N
16	Exit Terminate	Event Only	Silent	N	N	N	N	N	N
17	Holdup	Holdup Delay	Silent	N	N	N	N	N	N
18	24 Hour Local Sounder	Instant	Silent	Y	N	N	N	N	N

Zone Options Table


Default Number	Default Name	Zone Options										Zone Reporting					Zone Contact Options			
		Bypassed Stay Mode	Forced Arm Enabled	Bypass	Cross Zone	EOL	Automatic Zone Test	Night Mode	Zone Inactivity Test	Follow Any Armed Area	Final Set Door	Single EOL	Delayed in Stay	Alarms	Alarm Restores	Bypass-Unbypass	Zone Lost-Low Battery	Zone Trouble and Restore	Normally Open	Fast Loop
1	Bypass			Y		Y							Y	Y	Y	Y	Y			130:BA
2	Bypass Stay	Y	Y	Y		Y							Y	Y	Y	Y	Y			132:BA
3	Bypass – Forced Arm		Y	Y		Y							Y	Y	Y	Y	Y			130:BA
4	Bypass – Cross Zone			Y	Y	Y							Y	Y	Y	Y	Y			130:BA
5	Fire		Y			Y							Y	Y	Y	Y	Y			110:FA
6	Panic		Y			Y							Y	Y	Y	Y	Y			120:PA
7	Silent Panic					Y							Y	Y	Y	Y	Y			122:HA
8	Normally Open no EOL			Y									Y	Y	Y	Y	Y	Y		130:BA

Default Number	Default Name	Zone Options										Zone Reporting					Zone Contact Options			
		Bypassed Stay Mode	Forced Arm Enabled	Bypass	Cross Zone	EOL	Automatic Zone Test	Night Mode	Zone Inactivity Test	Follow Any Armed Area	Final Set Door	Single EOL	Delayed in Stay	Alarms	Alarm Restores	Bypass-Unbypass	Zone Lost-Low Battery	Zone Trouble and Restore	Normally Open	Fast Loop
9	Normally Closed no EOL		Y										Y	Y	Y	Y	Y			130:BA
10	Gas Detected					Y							Y	Y	Y	Y	Y			151:GA
11	High Temp					Y							Y	Y	Y	Y	Y			158:KA
12	Water Leakage					Y							Y	Y	Y	Y	Y			154:WA
13	Low Temp					Y							Y	Y	Y	Y	Y			159:ZA
14	High Temp					Y							Y	Y	Y	Y	Y			158:KH
15	Fire Alarm Pull Station					Y							Y	Y	Y	Y	Y			115:FA
16	Night Mode	Y	Y	Y	Y		Y						Y	Y	Y	Y	Y			135:BA
17	Final Set Door		Y	Y						Y			Y	Y	Y	Y	Y			130:BA
18	Medical	Y			Y								Y	Y	Y	Y	Y			100:MA
19	Blank	Y	Y		Y								Y	Y	Y	Y	Y			130:BA
20	Blank	Y	Y		Y								Y	Y	Y	Y	Y			130:BA
21	Blank	Y	Y		Y								Y	Y	Y	Y	Y			130:BA
22	Blank	Y	Y		Y								Y	Y	Y	Y	Y			130:BA
23	Blank	Y	Y		Y								Y	Y	Y	Y	Y			130:BA
24	Blank	Y	Y		Y								Y	Y	Y	Y	Y			130:BA
25	Blank	Y	Y		Y								Y	Y	Y	Y	Y			130:BA
26	Blank	Y	Y		Y								Y	Y	Y	Y	Y			130:BA
27	Blank	Y	Y		Y								Y	Y	Y	Y	Y			130:BA
28	Blank	Y	Y		Y								Y	Y	Y	Y	Y			130:BA
29	Blank	Y	Y		Y								Y	Y	Y	Y	Y			130:BA
30	Blank	Y	Y		Y								Y	Y	Y	Y	Y			130:BA
31	Blank	Y	Y		Y								Y	Y	Y	Y	Y			130:BA
32	Blank	Y	Y		Y								Y	Y	Y	Y	Y			130:BA

Adding a User

The Aritech Reliance XR system supports up to 100 users. Each user is assigned a PIN code and a user number. This allows them to interact with the system.

1. Log in to the Web Server.



Sign In:

Enter Your Name:

Enter Your Password:

2. Enter your username and password. A master code is required to add users, by default this is "User 1" (with a space between "User" and "1") and "1234". Then click Sign In.
3. The Arm/Disarm screen will appear:




- Logout
- Arm/Disarm
- Zones
- Cameras
- History
- Users
- Settings




Area 1

Ready

4. Click Users.



- Logout
- Arm/Disarm
- Zones
- Cameras
- History
- Users
- Settings
- Advanced



Configure Users

Select User Sort By Name

User 1 (1)

User Number

First Name

Last Name

PIN

Language

User Type

5. Click Add.
6. Enter a unique PIN code between 4 and 8 digits.
7. Enter a First and/or Last Name.
8. Select a User Type:
 - **Master users** can arm and disarm areas. They can create, delete, or modify user codes. They can also change system settings.
 - **Standard users** can arm and disarm areas. But they cannot create users or review event history.
 - **Arm only users** can only turn on the security system, they cannot disarm, or dismiss any system conditions.
 - **Duress users** will send a duress event when they are used to arm or disarm the system.
 - **Custom users** can have additional permissions and settings configured.
9. Click Save.

Adding a Keyfob

1. Log in to the Web Server.
2. Click Settings.
3. Click Keyfobs.
4. Use the drop-down menu to select the keyfob number you want to add to the system.

The screenshot shows a web interface with three main sections:

- Settings Selector:** A blue header with a dropdown menu set to "Keyfobs" and three buttons: "Up", "Down", and "Save".
- Zone Add/Remove Functions:** A section with three buttons: "Learn", "Remove", and "Cancel".
- Select Keyfob to Configure:** A section with a dropdown menu set to "65 KeyFob", a "User" dropdown set to "Use FOB Number as Standard User", three checkboxes for "Police", "No Siren on Police", and "Auxiliary", a "Scene" dropdown set to "disabled", and a "Serial Number" input field containing "0".

5. Click Learn.

6. Trigger the keyfob learning function for 2 seconds (on 63-bit keyfobs hold down the arm and disarm buttons, on 80plus keyfobs hold down the Arm + 2 buttons). The screen will show the keyfob has been found and the Serial Number will appear.
7. The keyfob will have access to Area 1 and the panel will report the keyfob number to the Central Monitoring Station when it is used.
8. Click Save.

Advanced Keyfob Programming

Three levels of access are possible:

1. Area 1 only – this is the default behaviour after learning a keyfob. The User is set to “Use FOB Number as Standard User”.
2. All areas – Click the drop-down User menu to assign the keyfob a User number. The keyfob will inherit areas and permissions of that user. New users, the default Master user, and the default Standard user have access to ALL areas. The user number is reported to the Central Monitoring Station when the keyfob is used.
3. Custom permissions – Keyfobs can be restricted to selected areas.

Simple Method: navigate to the User menu and select a suitable Area Group. The arm and disarm buttons on the keyfob will arm/disarm all areas in the Area Group.

Advanced Method:

- a. Create a new User.
- b. Change the User Type to Custom.
- c. Assign an unused Permission to the User.
- d. Create one or more Area Groups. Each one has a set of selected areas.
- e. Modify the Permission and assign the appropriate Area Group to the Control Groups displayed. For example, the Permission can Away Arm both Area 1 and 2 but Disarm only Area 1.
- f. Return to the Settings – Keyfob menu.
- g. Select the User that has been created.

The keyfob is now linked to the custom user, and the custom permissions will be applied. When the arm button is pressed, all areas in the Away Arm Control Group will be away armed. When the disarm button is pressed, all areas in the Disarm Control Group will be disarmed.

Keyfob Options:

- Tick the Police option to allow Panic Alarms to be sent to the Central Monitoring Station when Arm + Disarm Buttons are pressed at the same time. In addition, the panel will display the status and sound audible alerts. Please consult with your Central Monitoring Station what action will be taken.

- Tick “No Siren on Police” for Silent Panic, when activated the Aritech Reliance XR will have no indication the panic has been triggered, the Silent Panic event will be sent to the Central Monitoring Station. Please consult with your Central Monitoring Station what action will be taken.
- Tick Auxiliary to allow the keyfob to send an Auxiliary Alarm. On the 63-bit keyfob this is performed when the LIGHT and STAR buttons are pressed at the same time, on the 80plus keyfob this is performed when 1 and 2 buttons are pressed. Please consult with your Central Monitoring Station what action will be taken.
- Select a pre-programmed Scene from the drop-down menu. When the Scene button is pressed on that specific keyfob, the Aritech Reliance XR will “run” this scene. On the 63-bit keyfob this is the LIGHT button, on the 80plus keyfob this is the 2 button.

Note: When programming the Scene under the Settings – Scenes menu, the “Scene Trigger” is optional, simply select up to 16 actions to be performed when the scene is “run” by the keyfob.

Configuring Email Reports

1. Log in to Aritech Reliance XR. Use an installer or master user account.
2. Click Settings.
3. Click Channels in the drop-down menu.
4. Click "Select Channel to Configure" where the Format is already set to Email.

The screenshot displays the 'Settings Selector' interface. On the left is a navigation menu with options: Logout, Arm/Disarm, Zones, Cameras, History, Users, Settings (highlighted), and Advanced. The main panel is titled 'Settings Selector' and features a 'Channels' dropdown menu. Below this are 'Up', 'Down', and 'Save' buttons. The 'Select Channel to Configure:' section shows a dropdown menu with '4 Email 1' selected, which is circled in red. The 'Channel Name' field contains 'Email 1'. The 'Format' dropdown menu is set to 'Email' and is also circled in red. Other fields include 'Account Number' (empty), 'Destination' (empty), 'Language' (English), 'Next Channel' (disabled), 'Event List' (1 Event List), and 'Attempts' (2).

5. Enter an email address in the Destination field.
6. Select an Event List.
7. Enter a Channel Name for future reference.
8. Click Save.

Installer and Engineer user types can customize Event List for selective reporting.


Enabling Push Notifications on Smartphone

Smartphones with the UltraSync+ app can receive push notifications from the panel when system events occur.


You will need to have a:

- Fully configured Aritech Reliance XR system that is connected to UltraSync.
- Apple IOS or Android smartphone with internet access.
- Apple / Google account details so the app can be installed and updated.
- The device must be signed into the relevant Apple ID / Google account so their servers can deliver the push notification to the device.


1. Open the UltraSync+ app.
2. Click the edit button next to the site you wish to receive notifications from.



3. Click Notification Services.



4. Enable Push Notifications.




5. Wait for the registration process to complete.

Note: A maximum of 13 devices can receive push notifications. Each device will occupy a Channel slot. Each channel will automatically be assigned the corresponding event list number.

6. Optional – select the events to be notified for:

a. Click Show event selection.



b. Select the events you want a notification for.

c. Click Save >.

d. Click Back.

7. Click Back.


8. Click Done.

Note: If the device will no longer be used, repeat these steps and disable Push Notifications to free up the channel position for future use. Alternatively, if the device is not available, login to the panel web page (Settings – Channels) and delete the device name from the destination field.


Troubleshooting Notifications

If notifications are not working:


- Check you can see the Arm/Disarm screen of the device you wish to receive notifications from, this ensures you have authority to access the Aritech Reliance XR.



- Check the Aritech Reliance XR has at least one unused channel: log in, click Menu, Settings, Channel, then click the drop down, at least one channel should have a blank Destination.
- Check your site is registered for notifications in the app (follow instructions above).




- Check your smartphone has notifications enabled (on Apple iOS click Settings, Notifications, scroll down and click UltraSync, check “Allow Notifications” and “Show in Notification Centre” are enabled, optionally select the Alert Style as Banners or Alerts).
- If you are on iOS, ensure your phone is logged into your Apple account under iTunes or iCloud.
If you are on Android, ensure your phone is logged into your Google account under Google Play or Settings. This is required as UltraSync sends the push notification to Apple and Google servers for delivery to your device. “Rooted” or “Jailbroken” phones may not have the required software to receive push notifications.
- Update your device to the latest version.
- If you have multiple devices registered to receive notifications, each device must have a unique name. This is set in the UltraSync+ app:
 1. Touch Menu  from the Sites screen.
 2. Touch Global Settings.
 3. Touch Notification Services.
 4. The device name is displayed and can be changed.



Removing Notifications

Follow the steps above and disable the “Push Notifications” option. This will automatically delete your device from the server and Aritech Reliance XR.



If you do not have access to the device, the Aritech Reliance XR can be modified to stop sending the notifications:

1. Log in to the Web Server.
2. Click Settings.
3. Click Channels from the drop-down list.

- Click the Channel Number in the drop-down list, your device name will appear.

The screenshot shows a sidebar menu on the left with 'Settings' highlighted. The main panel is titled 'Settings Selector' and has a 'Channels' dropdown menu. Below it are 'Up', 'Down', and 'Save' buttons. A 'Select Channel to Configure:' dropdown is open, showing a list of channels. The channel '4 smartphone_u1' is selected and circled in red. Below this, the 'Channel Name' field is populated with 'smartphone_u1'. Other fields include 'Account Number' (0), 'Format' (Email), 'Destination' (smartphone@u1), 'Language' (English), 'Next Channel' (disabled), 'Event List' (4 Event List), and 'Attempts' (3).

- Delete the content of the Destination field.

The screenshot shows the same 'Settings Selector' interface. The 'Destination' field, which previously contained 'smartphone@u1', is now empty and circled in red. All other fields remain the same as in the previous screenshot.

- Click Save.
- Your device will no longer receive notifications from this Aritech Reliance XR and the Channel is available to be reused.

Reporting to a Control Room

1. Ask Control Room to provision panel in UltraSync Portal.
2. Log in to the Web Server.
3. Click Settings.
4. Click Channels from the drop-down list.
5. Channel 1 is displayed. Change Format to UltraSync.
6. Click Save.
7. Panel will attempt to register on to the UltraSync servers. If successful, the panel will obtain "Service Grade" settings. This configures primary and secondary paths, the timers for path fail detection, and when path fail is reported to the control room/local panel. This process should take under 5 minutes from power up.

Troubleshooting

If the control room advises the panel is not reporting:

- Log in to Web Server and check Settings – Connection Status.
- If IP/ethernet path is provisioned, check the panel has access to the internet. For example, the customer's router may not be working, or the internet is temporarily unavailable.
- If cellular path is provisioned, check the signal level, and allow 3-5 minutes for the SIM card to register on to the cellular network, and connect to UltraSync.
- Ask control room to check correct serial number is provisioned on UltraSync Portal. The panel serial number can be viewed under Settings – Details.
- Ask control room to check Service Grade.
- Power cycle the panel, this forces the panel to perform the registration process.
- Ask control room to check SIM card.

DLX900 Software

DLX900 is a tool for programming Aritech Reliance XR systems. This software is installed on a PC with Microsoft Windows 7, 8, or 10. It features a graphical interface, allowing installers and Central Monitoring Stations to program and manage complex sites.

Customer details and all panel programming are stored in a local database on the computer. This allows companies to create standard templates for quicker programming of customer panels.

Installing DLX900

Download the latest version from <https://www.ARITECH.com/library>

You will need administrator privileges to install DLX900.

Double click the installation file and select the correct region. This will affect the panels the software will support.

Upgrading from DL900

DLX900 in Australia supports legacy NetworX panels.


If DL900 has been installed previously, DLX900 can automatically import and upgrade the database. It is recommended you save a backup of your database and ensure you have a copy of DL900 in case you need to revert.

Once DLX900 is installed, right click the icon, click “More”, and select “Run as Administrator”

Login to DLX

Default username and password for DLX900 is *UTC 1234*.


Enter this twice (once for master access, once for operator access) to login.




The image shows a standard Windows-style dialog box titled "Master access". It features a title bar with a minus sign, a maximize button, and a close button. The main area contains two text input fields. The first field is labeled "Operator" and contains the text "UTC". The second field is labeled "Password" and contains masked characters "xxxxx". Below these fields are two buttons: "OK" and "Cancel".

You must change the password. To change the default accounts and passwords: click Program – Setup – Add/change Operators. Click the user then “Set Password”.

To enable or disable password prompt(s): click Program – Setup – Program Setup.




Navigating the Main Window



1. Window Title – displays currently selected customer’s account number.
2. Menu Bar – Program contains settings for DLX900, View turns on/off Toolbar and Status Bar, View also has shortcut to the customer list, Control Panel displays all top-level programming menus for the currently selected customer’s control panel, Devices displays all programmed expansion devices, Download displays connection commands, Tools displays DLX900 database management tools and Diagnostics.
3. View Customer – add/edit/delete customers, select customer to view.
4. View Customer List – show all customers in current DLX900 database.
5. Call control panel – use PSTN modem to connect to control panel.
6. Connect TCP/IP – connect to control panel using TCP/IP.
7. Disconnect – end current session and disconnect from control panel.
8. Send all data – send all programming menus from DLX900 to control Panel.
9. Read all data – read all programming data from control panel into DLX900.
10. View Status – view control panel system status (armed state, alarms, and troubles).
11. Read All Event Log – retrieve all event history.
12. Read 10 Events – retrieve last 10 items from event history.
13. Devices Enrolled – drop-down menu with shortcuts to enrolled expander devices.
14. Control Panel Menu – shortcuts to control panel settings, available on selected panels.

15. DLX900 Status – shows a progress bar of read and send commands, Caps Lock, Scroll Lock, Num Lock, and Online/Offline connection state to control panel.

Customer Window



The screenshot shows a software window titled "Customer - 1111". It contains several input fields and buttons. The "Account number" field is highlighted with a red oval and contains the value "1111". To the right of the main form, a vertical column of buttons is also circled in red: an up arrow, a down arrow, "New Customer", "Duplicate Customer", and "Delete". Other fields include "Name", "Address", "City", "State", "Zip code", "Contact phone", "Contact phone 2", "Panel phone", "Panel" (set to "ZeroWire"), "Connect TCP/IP" (set to "Using Known IP Address"), "IP Address", "IP Port", "Serial Number", "Web Access Passcode", "Installation Date" (set to "Invalid"), and "Last Diagnostic Date". There are "Goto..." buttons next to several fields. At the bottom left, there is an "Additional items >>" button.

Each customer must have a unique Account Number.

Selecting a Customer

DLX900 will load programming for the currently displayed customer in any menus displayed. Select a customer by:

- Using the Up and down arrow buttons to navigate through your customers;
- Entering the customer's detail in the name or contact phone field, then click Goto;
- Clicking the Account number Goto, then enter the account number; or
- Clicking View Customer List, then click the customer displayed.


Duplicating a customer

DLX900 allows easy duplication of customer programming for similar sites.

1. Select a customer with the programming to duplicate.
2. Click Duplicate Customer.
3. Enter a new Account Number.
4. Tick "Copy customer information" if you want the contact details and serial number of the panel to also be copied. This is useful if you are testing new programming for the same customer.
5. Click OK.

Navigating the Menus


Each menu has a set of common elements:



1. Menu Name – displays the menu name and current customer’s account number.
2. Menu Bar – commands to Send data to the panel, read data from the panel, and Options to restore factory defaults for this menu.
3. Tool Bar – Search for customers, send only this menu’s data to the panel, Read only this menu’s data from the panel, Add a new record, Copy the current record, and Delete the current record.
4. Navigation Buttons – jump to the first record, go back one record, enter a record number, see the number of records for the current menu, go forward one record, jump to the last record.
5. Sub-menu Tabs – these reflect the sub-menus in the Reference Guide.
6. Programming options – changes to these settings are saved immediately to the database, to make them “active” perform a Send command.

Control Panel Menu

This menu features all programming locations for the main panel. For supported models, these menus also appear on the left side of the Main Menu.




Loading Control Panel Defaults

DLX900 can load factory default data for the currently selected customer panel:

1. Click Control Panel.
2. Click Default Control data from – Factory defaults.

Devices Menu

The Devices Menu displays all expansion devices including keypads, input expanders, output expanders, power supplies, touchscreen tablets, wireless devices, and keyfobs.




Each of these devices may have separate programming stored inside that device. This menu allows you access to those programming locations.

Programming is retrieved from all enrolled devices when you perform a Read All.

Device Info

Click Devices – Device Info to show all expansion devices:




The Device Info menu allows:

- Adding and removing of devices – click Remove Device, Auto Enroll, Manual Enroll, or Add Device under the device category.
- Identification of devices – click Turn on / off Buss LED to flash an LED of the specific device.
- Re-ordering of devices – drag and drop the device to re-number it, use the “Slot condition after removing device” to determine if DLX900 should refresh all device numbering or to reserve the device number for future use.
- Display of device information including firmware and serial number.
- Access programmed data – select the device and click Display Stored Data, this is the same as accessing the device via the Devices Menu.
- Export of programming information for a specific device – select the device and click Create file. DLX900 will create a special file. This file can be copied to a USBUP and then inserted into a suitable device to program it without a computer.
- Export control panel information for use with USBUP – on the Control Info tab click Create file to save current panel programming to a special file. This file can be

copied to a USBUP and then inserted into a Aritech Reliance XR system to program it without a computer.

Download Menu



This menu allows you to:

- Initiate a connection to the panel.
- Disconnect from a panel.
- Read all programming, including all connected expansion devices and backup copies where available.
- Send all programming to the panel.
- Read the event log.
- Initiate a callback session before download, where this feature is enabled on the panel.
- Write programming to a NX-586 / NX-588. This allows on-site programming of selected panels without the need for a computer.
- Read programming from a NX-586 / NX-588. This allows retrieval of panel programming from selected panels on-site without the need for a computer.
- Enable auto-answer for callback.

Reading Data

All programming located inside a customer panel can be retrieved and stored in the DLX900 database for further editing or backup purposes.

Reading All Data

To retrieve the contents of all control panel menus and store it in DLX900:

1. Select the customer you want to connect to.

2. Connect to the panel.
3. Click the Read All button on the toolbar. Alternatively, from any menu click Read – Read Control to only retrieve panel programming without data stored inside expansion devices.
4. Wait for the progress bar on the bottom right to complete. DLX900 will retrieve data from multiple menus, each will have its own progress bar.
5. Disconnect from the panel.
6. All data is now stored in your local database. Any changes made in DLX900 will not be reflected in the customer panel. To make changes “live”, follow the instructions on Sending All Data.

Reading Data from a Selected Menu

Programming from a single menu can be retrieved from the control panel into DLX900:

1. Select a customer to connect to.
2. Connect to the panel.
3. Open the menu you wish to read.
4. Click Read – Read Menu.
5. Data from all tabs in the current menu will be read into DLX900. Wait for the progress bar on the bottom right to complete.
6. Disconnect from the panel.

Sending Data

Once programming has been created in DLX900, it must be sent to the panel using a “Send” command.

Sending All Data

To send the contents of all DLX900 menus to the control panel:

1. Select the customer you want to connect to.
2. Make all changes required to customer programming.
3. Connect to the panel.
4. Click the Send All button on the toolbar. Alternatively, from any menu click Send – Send Control.
5. Wait for the progress bar on the bottom right to complete. DLX900 will send data to multiple locations in the panel, each will have its own progress bar.
6. Disconnect from the panel.
7. All panel programming has been copied to the panel.

Sending Data from a Selected Menu

Programming from a single menu can be sent from DLX900 to the control panel:

1. Select the customer you want to connect to.
2. Connect to the panel.
3. Open the menu you wish to send.
4. Click the Send – Send Menu.
5. Data from all tabs in the current menu will be sent to the panel. Wait for the progress bar on the bottom right to complete.
6. Disconnect from the panel.

Tools Menu

This menu provides database management features to maintain DLX900. This includes:

- Compact Database – The database may grow in size over time with adding and removing of customers. Click this option to clean the database and make it smaller.
- Repair Database – DLX900 will check the database for any errors and repair them where possible.
- Backup Database – The database should be regularly backed up and copied off the computer to a secure location. DLX900 will regularly request to perform a backup of the database when you exit the program. To change the frequency of the backup request, click Program – Setup – Program Setup – Backup Schedule.
- Restore Database – The database can be restored to a new computer if required.
- Import Customers – Specific customers can be recovered from an existing database backup file. This will read all customers or a specific customer (account number) into the current database.
- Export Customers – Specific customers can be saved to a new database.
- Diagnostics – Display real-time communication data between the panel and DLX900.

Programming with DLX900

This section of the manual will describe the steps needed to program each feature using the DLX900 software.

Selected screen shots of the Aritech Reliance XR Web Server are also included for your reference. Similar screens appear on the UltraSync+ app.

Programming Instructions for System Options

Goal

Program System Options including time and date, tamper, siren, timers, and service settings.


Pre-conditions

Time and date are automatically updated using a internet time server by default, this setting is enabled under Communicator – IP Config.

If you want to allow Aritech Reliance XR to send diagnostic emails, then check email is set up correctly under Communicator – Email and Aritech Reliance XR is connected to a network.


Note: Ensure you set the correct time zone here.

Programming Sequence




Instructions


1. Open System



2. Select the right Time Zone using the Hours and minutes offset
3. If you wish to update the time and date
4. Go to System and Siren Options




5. Select the settings you want to enable
6. Go to Timers



7. Enter the settings for global timers. Note Entry/Exit times are not here, go to Areas-Area Timers.

8. Go to Maintenance and Test



9. Enter a Diagnostic email interval. This is the number of days to wait before sending an email at the specified time. This verifies email communication is working.

Web Page

Logout
Arm/Disarm
Zones
Cameras
History
Users
Settings
Advanced

Settings Selector

System

Control Name

Language

Voice Language

System Date and Time

Date:

Time (hh:mm:ss) :

System Time Zone

Hours Offset

Minutes Offset

System Daylight Saving Time

Start Month

Start Week

End Month

End Week

System Timers

Siren Time [0-99] Minutes

Battery Test Time [0-99] Minutes

Battery Missing Time [0-65] Seconds

AC Failure Report Delay [0-999] Seconds

Cross Zone Time [0-999] Seconds

Zone Inactivity Time [0-65535] Minutes

Fire Supervise Time [120-65535] Seconds

Burg Supervise Time [120-65535] Seconds

System Options

Panel Zone Doubling

Panel Box Tamper

System Zone Tamper

Disable Hardwired Zones

Zone Inactivity

System Reporting

System Channels

Programming Instructions for Permissions


Goal

Create a list of permissions that will restrict users, keypads, and devices to specific parts of the system.

Pre-conditions


Have programmed or customized Channel Groups, Area Groups, Menus, and Action Groups. Alternatively, you can use the preset groups.

Programming Sequence




Instructions

1. Open Permissions



2. Select the permission number you want to modify
3. Enter a functional name for the permission
4. Select the Groups for each item which will give access to the items selected inside the group. For example, if this permission is assigned to a user, then that user will have access to Arm each of the Areas that are selected inside the Area Group and no others.
5. Click the Options/Timers tab



6. Select the user options that you want to apply to this permission. Descriptions of each item are available in the Aritech Reliance XR Reference Guide.

Next

- Program Users or Devices

Programming Instructions for Menus

Goal

Create a list of menus that a user or device has access to on the Aritech Reliance XR system.

Pre-conditions

None.


Notes

The menus that will be available are the ones that the device has permission to display AND the ones that a user has access to, at the specified time and date which is controlled by Schedules.

Users have up to 4 levels of access and devices have up to 2. This allows very sophisticated and fine-grained control of access.


64 custom menus can be created. The preset ones will help you create a system quickly without needing to modify these.

Programming Sequence



Instructions

1. Open Menu



2. Select the Menu number

3. Enter a descriptive name

4. Tick each item that you want a user / device to have access to.

Next

- Program Permissions
- Assign the Permission to a User or a Device

Programming Instructions for Holidays

Goal

Create a list of holidays to provide or prevent access to the Aritech Reliance XR system on the specific dates.

Pre-conditions


None.

Notes

Ticking Holidays in a Schedule for a permission PREVENTS access.


Holiday schedules may impact automation features such as Actions if they are in use. For example, you may not want an Action to play on a holiday, so take care in programming the associated Schedule and permissions.

Programming Sequence



Instructions

1. Open Holidays



2. Select one of the 4 Holidays available
3. Enter a name for the Holidays
4. Enter the start and end date for each holiday you have

Next

- Program Schedules

Example



Office Worker
 User Permission 1 – All Areas
 Office Schedule 1 – 8am-8pm M-F,
 Holidays 1 (ticked)


An office is not staffed during a public holiday and you want to **prevent** access to the building to staff on this date.

The public holidays in NSW, Australia for 2019 are:


New Year's Day	1 January
Australia Day	26 January
#Additional Day	28 January
Good Friday	19 April
Day following Good Friday	20 April

Easter Sunday	21 April
Easter Monday	22 April
Anzac Day	25 April
Queen's Birthday	10 June
Labour Day	7 October
Christmas Day	25 December
Boxing Day	26 December


Open Holidays and program the date ranges.



Next, go to Schedules and **tick** "Holidays 1":



Then assign that schedule to the User:



Programming Instructions for Users

Goal

Add/Edit/Remove users from your Aritech Reliance XR system.

Pre-conditions

- Have programmed or customized Permissions. Alternatively, you can use the defaults.
- Have programmed or customized Schedules. Alternatively, you can use the defaults.

Notes

PIN codes must be unique across the system, no two users can share the same PIN code.

PIN codes must be 4 to 8 digits in length.


Username must be assigned to give that user access to UltraSync+ app or Aritech Reliance XR Web Server. A user with no first name will be unable to gain remote access.

The default installer account is User 256 with username **installer** and PIN **9713**, with Master Engineer user type. These details are used to Log in to the Web Server web pages and UltraSync+ app.

The default master account is “**User 1**” and PIN **1234**


The default standard account is “**User 2**” and PIN **5678**

Programming Sequence



Instructions


1. Open Users



2. Select the User number you want to modify with the Left and Right arrow keys on the top right. You can also Search, Add, Copy, and Delete a user by clicking the corresponding button on the toolbar.




3. Enter a first name and/or last name for the user. It is case sensitive and provides the username to log in from the UltraSync+ app.
4. Enter a new PIN code for the user. It must be unique and 4-8 digits long.
5. Select the user type that you want to apply to this user. Descriptions of each type are available in the Aritech Reliance XR Reference Guide.
6. The Status option determines if that user can interact with the system, or if their access has expired.
7. Click the Advanced tab.



8. You can set the start/end date and time for when this user will have access to the system. This can be used to provide temporary user access. If Active is selected on the previous tab, then the end date and time on this screen will be set to maximum.
9. You can program up to 4 levels of access for each user. Permission 1 is applied when Schedule 1 is true.
 The combination of one Permission and one Schedule is called a “Permission Profile” (left drop-down menu). Permission Profile 1 is the highest level and will override Permission Profile 2 when Schedule 1 is active. Refer to Aritech Reliance XR Reference Guide for more details.
 To enable Permission Profiles the user type must be first set to Custom on the Main tab.

Web Page



Configure Users

[Add](#) [Edit](#) [Delete](#) [Save](#)

Select User Sort By Name

User 1 (1) ▼

User Number:

First Name:

Last Name:

PIN:

Language: ▼

User Type: ▼

Start: ▼

End: ▼

Profile 1: ▼
 ▼

Profile 2: ▼
 ▼

Profile 3: ▼
 ▼

Profile 4: ▼
 ▼

Programming Instructions for Zones

Goal

Program zones and add them to Areas.

Pre-conditions

None.

Notes


Use defaults for Zone Types and Zone Options to quickly set up your system.

Zones can have one or two profiles. The first profile will be active during the selected schedule, it takes priority over the second profile/schedule. The second profile will be active during the selected schedule if the first profile is not active.

If no schedule is set (or is currently active) in either the first or second zone profile, then the zone will be disabled.


See the next section for programming custom zones.

Programming Sequence



Instructions

1. Go to Zones.



2. Select a zone number you want to program.
3. Enter a name for the zone.
4. Select a zone type preset.
5. Select a zone option preset.
6. Select an Area Group for the zone. If you want a zone to be in its own Area, then select an Area Group with only one Area. To create a zone in a common Area, select an Area Group with multiple Areas. Alternatively come back to this step later.

7. For a standard installation set the schedule to a preset which is 24 hours every day, holidays should NOT be ticked in this schedule. This will enable the first zone profile. If you want the zone settings to change based on a schedule, then select the first schedule here.
8. If you are setting up a keyswitch zone, then the user number field controls which user profile will be used to arm/disarm. The keyswitch zone will report as default User 99.
9. If you are programming a second zone profile, then go to that now and repeat steps 4-7.

Web Page

The screenshot displays a web interface for configuring a zone. On the left is a navigation menu with the following items: Logout, Arm/Disarm, Zones, Cameras, History, Users, Settings (highlighted), and Advanced. The main content area is titled 'Settings Selector' and includes a dropdown menu for 'Zones', 'Up', 'Down', and 'Save' buttons. Below this is a section for 'Zone Add/Remove Functions' with 'Learn', 'Remove', and 'Cancel' buttons. The main configuration section, 'Select Zone to Configure:', shows '1 Zone' selected. Fields include Zone Name, Zone Type (set to '3 Entry Exit Delay 1'), Zone Options (set to '1 Bypass'), Partition Group (set to '1 Partition 1'), and Serial Number (set to '0'). There are also checkboxes for Tamper, Disable Internal Reed, and Norm Open External Contact, all of which are currently unchecked. Signal Strength is set to '0'. At the bottom, there are four dropdown menus for Voice Name 1 through Voice Name 4.

Next

- Zones are assigned to one or more Areas using Area Groups. If necessary, program Areas and Area Groups, then assign an Area Group to each zone (step 6).

Programming Instructions for Custom Zones


Goal

Program zones with advanced customization, including setting zone behavior to follow a schedule or armed/disarmed state.

Pre-conditions

Program the schedule you want the zone to follow if needed. Alternatively use the defaults.

Programming Sequence



Instructions

1. Go to Zone Type.

The screenshot shows the 'Zone types - 1' window with the following configuration:

- Profile: 1 Day Zone
- Name: (empty)
- Area Armed:
 - Zone Attribute: Instant
 - Siren Attribute: Yelping
 - Code Pad Sounder:
 - Report delay:
 - No Code Pad Display:
 - Momentary Switch:
 - Zone Inhibit:
 - Swinger Shutdown:
- Area Disarmed:
 - Zone Attribute: Trouble Zone
 - Siren Attribute: Silent
 - Code Pad Sounder:
 - Report Delay:
 - No Code Pad Display:
 - No Latching:
 - Zone Inhibit:
 - Swinger Shutdown:


2. Go to Zone Options.

The screenshot shows the 'Zone Options - 1' window with the following configuration:

- Profile: 1 Bypass
- Name: (empty)
- Zone Report Event: 134:BA
- Options:
 - Bypassed Stay Mode:
 - Forced Arm Enabled:
 - Bypass:
 - Twin Trip:
 - EOL:
 - Automatic Zone Test:
 - Night Mode:
 - Zone Inactivity:
 - Follow Any Armed Area:
 - Alarms reporting:
 - Alarm restore reporting:
 - Bypass-Unbypass reporting:
 - Sensor Lost-Low Battery reporting:
 - Sensor Trouble and Restore reporting:
 - Normally open:
 - Fast Loop:

3. Select the options you want, the SIA/CID event code can be customized. See the Aritech Reliance XR Reference Guide for a table of codes.
4. Go to Zones.

5. Select a zone number you want to program.
6. Enter a name for the zone.
7. Select the zone type profile you just created.
8. Select the zone options profile you just created.
9. Select an Area Group for the zone. If you want a zone to be in its own Area then select an Area Group with only one Area. To create a zone in a common Area, select an Area Group with multiple Areas. Alternatively come back to this step later.
10. For a standard installation set the schedule to a preset which is 24 hours every day, holidays should NOT be ticked. For example, "Always On". This will enable the first zone profile.
If you want the zone settings to change based on a schedule, then select the first schedule here.
If no schedule is set in either the first or second zone profile then the zone will be disabled.
11. If you are setting up a keyswitch zone, then the user number field controls which user profile will be used to arm/disarm. The keyswitch zone will report as default User 99.
12. If you are programming a second zone profile, then go to that now and repeat steps 4-7.



Next

- Zones are assigned to one or more Areas using Area Groups. If necessary program Areas and Area Groups, then assign an Area Group to each zone (step 8).

Programming Instructions for Areas


Goal

Program Areas, Entry/Exit Times, Reporting Options, and Area Groups.

Pre-conditions


Programmed Communicator, Channels, and Channel Groups.

Programming Sequence




Instructions

1. Go to Areas.




2. Select an Area Number.
3. Enter a descriptive name.
4. Select the Options you want to enable for this Area. Area 2 and above have “Use Area 1 Options” ticked to allow faster programming of your system. Untick this box if you want to customize options for Area 2 and above.

5. For advanced programming you can assign a Schedule and an Area Time Disarm function to occur according to the schedule. Refer to the Aritech Reliance XR Reference Guide for more details.
6. Go to Area Timers.



7. Enter the timers that apply to this Area.
8. Go to Area Reporting.



- Assign the Area an account number and the Channel Group you want this Area to report to. See Programming Instructions for Zone Reporting for more details on how this works.

Next

- Customize Area Groups if needed.

Webpage

The screenshot displays the 'Settings Selector' webpage interface. On the left is a vertical navigation menu with the following items: Logout, Arm/Disarm, Zones, Cameras, History, Users, Settings (highlighted), and Advanced. The main content area is titled 'Settings Selector' and includes a dropdown menu for 'Partitions' with 'Up', 'Down', and 'Save' buttons. Below this is a section for 'Select Partition to Configure:' with a dropdown showing '1 Partition' and a text input for 'Partition Name'. The 'Partition Timers' section contains six input fields: 'Entry Time 1 [0-45] Seconds' (30), 'Exit Time 1 [0-240] Seconds' (60), 'Entry Time 2 [0-90] Seconds' (30), 'Exit Time 2 [0-240] Seconds' (60), and 'Stay Entry Time [0-45] Seconds' (30). The 'Partition Options' section lists seven checkboxes: Quick Away, Quick Stay Mode Disarm, Manual Panic, Manual Panic is Silent, Manual Fire, Manual Auxiliary, and Force Arm With Bypass. The 'Partition Reporting' section includes a text input for 'Partition Account' (0) and a dropdown for 'Partition Channels' (1 Channel Group).

Programming Instructions for Schedules

Goal

Create a schedule to provide or prevent access to the Aritech Reliance XR system on the specific dates and times.

Pre-conditions


Holidays have been programmed if needed.

Notes

Ticking Holidays in a Schedule PREVENTS access on the holiday dates.

Artech Reliance XR automatically handles schedules that span midnight (e.g. bakers' hours), do not tick the following day of the AM hours. (See Reference Guide for more details.)

Programming Sequence



Instructions

1. Go to Menu 7 – Schedules.

	1	2	3	4
Start time	8:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM
End time	8:00:00 PM	12:00:00 AM	12:00:00 AM	12:00:00 AM
All Days	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
All Weekdays	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
All Weekends	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Monday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Tuesday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Wednesday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Thursday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Friday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Saturday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Sunday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Holidays	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Holidays 2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Holidays 3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Holidays 4	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

2. Enter a name for the Schedule.
3. Select the first Start and End time.
4. Select the days you want this start and end time to apply to.

5. If you are using the DLX900 software you will be able to see 4 sets of times and days, click the drop-down in the middle to access more. Each schedule can have up to 16 sets of times and days.
If you are using an NXX-1820- , press the Up and Down buttons to access the 16 sets of times and days.
6. To allow an Action to control when this Schedule is active/inactive, select the Follow Action Number.
7. Now the schedule is ready to be assigned to a User or used by another part of the system.

Webpage

- Logout
- Arm/Disarm
- Zones
- Cameras
- History
- Users
- Settings**
- Advanced

Settings Selector

Schedules ▼

Up **Down** **Save**

Select Schedule to Configure: 1 Schedule ▼

Schedule Name

Time and Days 1

Start Time (hh:mm) :

End Time (hh:mm) :

Monday

Tuesday

Wednesday

Thursday

Friday

Saturday

Sunday

Holidays 1

Holidays 2

Time and Days 2

Start Time (hh:mm) :

End Time (hh:mm) :

Monday

Tuesday

Wednesday

Thursday

Friday

Saturday

Sunday

Holidays 1

Holidays 2

Time and Days 3

Start Time (hh:mm) :

End Time (hh:mm) :

Monday

Tuesday

Wednesday

Thursday

Friday

Saturday

Sunday

Holidays 1

Holidays 2

Time and Days 4

Start Time (hh:mm) :

End Time (hh:mm) :

Monday

Tuesday

Wednesday

Thursday

Friday

Saturday

Sunday

Holidays 1

Holidays 2

Example

For example, you could create a 24/7 schedule and then have this schedule follow an action. Next assign a keypad permission this schedule. Now based on what the action does, we can conditionally enable or disable a keypad. This provides a high level of flexibility and multiple sets of rules using actions can be set up like this.

Programming Instructions for Arm-Disarm

Goal

Automatically arm and disarm your Aritech Reliance XR system.

Pre-conditions

Areas have been programmed.

Notes

After Arm-Disarm is programmed, a user must arm the system to initiate the function.

The Arm-Disarm will function as if it is the user you select. You will need to program valid user permissions including Area Groups, User Schedule, Profile levels, and active date and time.


Creating a new user only for the purpose of Arm-Disarm will make it easier to maintain.

Use defaults for Schedules, Area Groups and Permissions for faster programming.

Aritech Reliance XR will sound a warning prior to the Arm-Disarm from arming an Area. This is set in Areas – Area Timers – Area Type Delay.


If a user with Area Type Override option disarms an Area with Arm-Disarm, then the Arm-Disarm will no longer function on that Area. To re-enable Arm-Disarm that Area must be manually armed.

Programming Sequence




Instructions


1. Create an Area Group and select the Areas you want to be Armed according to the schedule you will create later.




2. Create an Area Group and select the Areas you want to be Disarmed according to schedule. This can be the same or different as the Area Group you selected above.
3. Create a Permission and select the corresponding Area Group for Arm and Disarm.




4. Open Users and create a new user. Suggested you provide a descriptive name such as "Auto Arm User" to make troubleshooting in the future easy.



5. Go to the Advanced tab.



6. Select the Permission you created above. If you want a simple Arm-Disarm then leave the Schedule here as Always On. The Schedule selected here is only for the **User**. It determines when the User is allowed to perform an Arm-Disarm, not when the Arm-Disarm will occur.



7. Create a Schedule for when you want the Arm-Disarm to occur.

Schedules - 1

Send Read Options Display

Schedules

Schedule: 1 Schedule name: Office Schedule 1 Follow Action Number: Disabled

Time and Days: 1-4

	1	2	3	4
Start time	8:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM
End time	8:00:00 PM	12:00:00 AM	12:00:00 AM	12:00:00 AM
All Days	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
All Weekdays	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
All Weekends	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Monday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Tuesday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Wednesday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Thursday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Friday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Saturday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Sunday	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Holidays 1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Holidays 2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Holidays 3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Holidays 4	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

8. Open Arm-Disarm.

Arm-Disarm - 1

Send Read Options Display

Auto Arm-Disarm

Auto Arm-Disarm number: 1 Auto Arm-Disarm name: Office Arm-Disarm User number: 99 Auto Arm-Disarm schedule: Office Schedule 1

9. Select the Arm-Disarm number.

10. Enter a descriptive name for this Arm-Disarm.

11. Enter the User number you created above.

12. Select the Schedule for when you want to automatically Arm-Disarm the system.

13. Test the Arm-Disarm to ensure it is working as you want.


Example

An office with 3 Areas wants to automatically be disarmed during office hours, and armed out of office hours.

We create Schedule 4 Mon-Fri 9am-5pm. Then User 55 with permission to arm and disarm Area 1, 2, and 3 at any time or day.

Then each weekday at 9am the system will disarm Areas 1, 2, and 3 as if it were user 55 and report those disarm events (openings) to the communication channels specified.

At 5pm each weekday the system would arm Areas 1, 2, and 3 as if it were user 55 and report those arm events (closings) to the communication channels specified.



Programming Instructions for Communicator


Goal

Configure each communication path for delivering event messages.

Pre-conditions


None.

Programming Sequence




Instructions


1. Open Communicator.




2. Select reporting options.
3. Select when you want Aritech Reliance XR to perform an automatic communication test.
4. Click IP Config.



5. Edit IP settings for the Aritech Reliance XR system, if DHCP is enabled on the Aritech Reliance XR and a DHCP server is available, then this screen will automatically be filled in.
 - Enable Clock Updates – will keep the time and date correct using the provided Internet Time Server, no manual adjustment will be needed when daylight savings occurs provided the time zone is set correctly in System.
 - Monitor LAN – this will monitor the physical LAN connection and report communication fail if the cable is disrupted.
6. Click Radio and enter settings if required, this will depend on the SIM card and operator you are using.




7. Click Remote Access



8. Edit Remote Access settings for the Aritech Reliance XR system.

- Download Access Code – gives access to DLX900 to access the Aritech Reliance XR panel programming.

9. Click System Event Reporting.



10. Select the channel group to send system events (e.g. low battery)

Next

- Perform tests on each of the communication paths to verify they are functioning correctly.
- Program Channels.
- Program Channel Groups.
- Verify Number of Attempts, next channels (back-up channels), and multi-path reporting function correctly.

Programming Instructions for UltraSync

Pre-conditions

1. At least one user has been given a username and PIN code (see "Programming Instructions for Users" on page 87).
2. Aritech Reliance XR is connected to internet and has been allocated an IP address (see "Programming Instructions for Communicator" on page 107, IP Config).

Notes:

UltraSync provides a secure VPN connection to your Aritech Reliance XR system over the internet. You will need to provide your Aritech Reliance XR serial number, Web Access Passcode, and a valid Username and PIN code that exists in your Aritech Reliance XR system. These codes provide multiple levels of security for the connection.

The Web Access Passcode is needed for:

- web console over the internet via a secure VPN
- UltraSync+ app
- DLX900 software connecting over IP, in addition to Download Access Code

The Web Access Passcode is NOT needed for:


- email services
- web console over a local LAN connection

Once UltraSync is set up, you may connect to your Aritech Reliance XR system using the UltraSync+ app on your smartphone or tablet. This may require a separate account and downloading additional software. See further instructions in the User Manual.

Instructions

1. Go to Menu 6 – Communicator, 3 - IP Config.

2. Under sub-menu 12 - IP Options, tick the box “Enable UltraSync”.
3. Go to Menu 22 - UltraSync.



4. Enter a new 8-digit Web Access Passcode. All zeros will disable UltraSync remote access.
5. Enter the required details into your device/software. This includes the Aritech Reliance XR serial number, Web Access Passcode, and a valid Username and PIN code. The Aritech Reliance XR serial number can be found in the Device Info menu.
6. Verify the UltraSync service is working by using your device/software to connect your Aritech Reliance XR system.

Troubleshooting

- Check the Web Access Passcode is correct. It cannot be 00000000.
- Check there is a valid user, and they have a First name, this will be the login name.
- Check the serial number is correct. It is printed on the Aritech Reliance XR module.
- Check that the user permissions are currently valid.
- See Troubleshooting Section in the Appendix for more information.

Programming Instructions for Event Lists

Goal

Create segmented lists of events so Channels can selectively deliver event messages.

Pre-conditions


None.

Notes

If an event message is enabled in an Event List, then the Channel will attempt to deliver it. If an event message is not enabled on the Event List, the Channel will not attempt delivery even if the message has been sent to it.


Event List set up for push notifications is automatically performed by the UltraSync+ app when required. The panel will assign the next available channel and matching event list number. No configuration via the web pages or DLX900 is required.

Programming Sequence



Instructions

1. Open Event Lists.




2. Enter a name for the list.
3. Check the events you want to include in the list.

Example

In this example we have created two lists: Critical and Informational. This allows us to selectively deliver event messages to different destinations.

We open up Event Lists and enter the name "Critical". We tick Alarms, Alarm Restores, Bypass and Bypass Restore, and AC Fail Reporting.

Then we click to Event List 2 and enter the name "Informational". Tick Opening and Closing, and Autotest Report.



Programming Instructions for Channels

Goal

Set up communication paths and destinations for delivering event messages.

Pre-conditions

1. Communicator must be programmed (see "Programming Instructions for Communicator" on page 107).
2. Event Lists must be programmed (see "Programming Instructions for Event Lists" on page 112).
3. If reporting to a control room, the panel must be provisioned in the UltraSync Portal. The provisioning process sets the primary and secondary paths (IP/cellular), local path fail detection, and server-based path monitoring settings.

Notes:


Area Account Number will take priority over Account Number entered here for Zone events. If no Area Account Number is entered, then this number will be used instead.

Next Channel must be a higher value than the current Channel Number. Circular loops are not permitted.

Take note of the Sequence Attempts under Communicator – System Event Reporting (6.11.2). This is the number of times Aritech Reliance XR will attempt the sequence of Channels you set up in this section.


Channel set up for push notifications is automatically performed by the UltraSync+ app when required. The panel will assign the next available channel and matching event list number. No configuration via the web pages or DLX900 is required.

Programming Sequence




Instructions

1. Go to Channels.



2. Enter an Account Number up to 8 digits, hex values are accepted.
3. Select the Format of the communication channel, this will automatically use the settings programmed for that Format in the Communicator menu.
If reporting to a control room via UltraSync, this must be set to “UltraSync”.
4. Select the reporting device, by default Device 1 is the Aritech Reliance XR panel.
5. Enter the destination email address or IP address depending on which Format you selected.
If reporting to a control room via UltraSync, this can be left blank for SIA or CID event messages.
6. Select what events you want to be sent via this Channel by selecting the appropriate Event List. Events that arrive at this channel will be checked that they are on this Event List, if they are, then will be routed through this Channel. Events that arrive at this Channel which are not on this list will be blocked.
If the currently selected Channel is used for push notifications to UltraSync+ app, the Event List number must be the same as the Channel number.
7. Enter the number of Attempts that you want Aritech Reliance XR to try sending the event message on this Channel before switching to the Next Channel.
8. Select the Next Channel Number to use if the event message fails to be sent on this Channel.
Each Channel can have one Next Channel as a backup. This allows you to chain up to 15 backup paths should the primary one fail. Enter Next Channel as 0 to end the chain of channels.
9. You have now finished programming one channel. If you entered a Next Channel, then go to that Channel number and program that now.

10. Once you have programmed each channel and backup channel(s) you have completed this section. Check or edit Sequence Attempts under Communicator – System Event Reporting (6.11.2).
11. Go to Channel Groups. Here you will group channels together so selected event messages will be sent to multiple destinations at the same time. Another way to think of Channel Groups is “multi-path reporting”. Note this is in addition to WiFi/Ethernet and Cellular backup where equipped and provisioned by UltraSync Portal.



12. Select each channel you want to be part of a group.
Messages sent to a Channel Group will be checked against each Channel’s Event List. If it is on the list then Aritech Reliance XR will attempt to send it. If not, then Aritech Reliance XR will not send it, even if the Channel is in the same group.
13. Done. Your Channels are now set up and ready for use. When an event is generated by the system or a zone it can now be sent to a Channel for reporting.

Example


In this example we have multi-path, prioritised/selective event reporting via three reporting paths – one control room with backup, push notification to a smartphone, and an email address. These are grouped into “Channel Group 1”.

All alarms are reported to Control Room 1 and push notification goes to UltraSync+ app installed on User 1’s smartphone. Control room 1 has a backup receiver.

When a channel receives an alarm message, Aritech Reliance XR checks that the channel’s Event List includes alarm messages and then attempts to deliver the message via that channel.

When Channel 1/2/4 receives a low battery report, it is ignored because Event List 1 does not include the “low battery” event.

Low priority alerts such as opening and closings, low batteries, and auto test reports, are selected in Event List 2. Channel 6 handles Event List 2 and sends these events as an email to a building manager. When Channel 6 receives the Zone 3 in Alarm event it takes no action because Event List 2 does not include “Alarms”.



Notice that Channel 2 is not selected in Channel Group 1. The Aritech Reliance XR will deliver to Channel 2 only if Channel 1 cannot be reached. If Channel 2 were included in Channel Group 1, then the control room may receive duplicate messages.

Next

- Program your Areas and Zones.


Programming Instructions for Zone Reporting

Goal

Direct event messages (e.g. alarm, bypass, tamper) from zones to specific destinations.

Pre-conditions

- The zone must have valid zone options programmed (see "Programming Instructions for Zones" on page 90), by default you should not need to modify these.
- The zone must be allocated a valid Area Group (see "Programming Instructions for Zones" on page 90).



- Channels and Channel Groups must be programmed (see "Programming Instructions for Channels" on page 114).


Notes

Each zone may be allocated to multiple Areas through an Area Group.

Events will be sent to the lowest numbered Area in the Area Group.


A zone may have a Second Zone Profile, when this becomes active all events will be sent to the Area Group programmed in the second profile.

Programming Sequence




Instructions

1. Open the lowest Area number for the Zone.




2. Go to Area Reporting.



3. Enter an account number.
4. Select a valid Channel Group.
5. Done. All zones that are a part of that Area will now report to the selected Channels within the Channel Group.

Example



Next

- Program Users.
- Program advanced Schedules and Alternate Zone Profiles.

Programming Instructions for System Event Reporting

Pre-conditions


- Communicator must be programmed (see "Programming Instructions for Communicator" on page 107).
- Event Lists must be programmed (see "Programming Instructions for Event Lists" on page 112).
- Channels and Channel Groups must be programmed (see "Programming Instructions for Channels" on page 114).

Notes

The system event will only be reported by a channel, if that Channel includes that event in the associated Event List(s).


Take note of the Sequence Attempts under Communicator – System Event Reporting (6.11.2). This is the number of times Aritech Reliance XR will attempt the sequence of Channels you set up in this section.

Programming Sequence




Instructions

1. Go to Communicator, System Event Reporting.



2. Select a Channel Group.
3. Done. The Aritech Reliance XR will now report system events to the Channels selected in the Channel Group you just selected.


Example



Programming Instructions for Actions

Goal

Create an action to monitor up to four input events and drive one output event (action result).



Pre-conditions

Program the input and output events you want the Action to monitor or control.


Notes

See Aritech Reliance XR Reference Guide for more details on Actions.

Write/Plan out on paper what you want to create to make it easier to set up Actions and associated settings.

Actions can be used without programming an Action Result. For example, outputs are controlled by setting them to monitor an action, when the Action State is true the output state will follow.

Programming Sequence



Instructions

1. Open Actions.

2. Select the Action Number you want to create.
3. Enter a descriptive name for this action.
4. Select the Action Function and the duration (optional) for the **Action State**.
For example, timed 5 seconds would cause the Action State to activate for 5 seconds when all the conditions in the Event Equation are satisfied.
5. Select the Event 1 logic, this will be applied before Event 1.
For example, "Inverted OR" results in "NOT Event 1".
6. Program the first event by using the Category and Type menus.

7. Enter the Event Range for the selected Category.
For example, if you want to select Areas 1-4 then set the Event range Start=1 and End=4.
8. Select Event 2 logic and repeat for the remaining events.
9. If you want to program an action result, click the Result tab.

10. Select the Category, Type, Start and End Range.
11. Test the Action by satisfying the Event Logic and checking the desired response.

Next

- Program the device you want to monitor the Action if needed.
- If you want to control an Output, go to that Output and program it to follow the Action.
- If you want a user or device to have access to the action, then program Action Groups and Permissions.

Programming Instructions for Action Groups

Goal

Create a list of actions a user or device has access to.

Pre-conditions

Program the actions you want to use.

Notes


See Aritech Reliance XR Reference Guide for more details on Actions.

Action Groups can allow you to create a convenient menu for a user to trigger specific Actions from a NXX-1820- .

Permissions control what actions a User or Device has access to.


Both the User AND Device need to have access to the desired Action for it to be displayed on a NXX-1820- screen.

Programming Sequence



Instructions

1. Open Action Groups.



2. Select an Action Group Number.
3. Enter a descriptive Name.
4. Select the Actions you want to include.

Next

- Assign Action Group to a Permission.
- Assign Permission to a User or Device.

Programming Instructions for Scenes

Goal

Create a scene that performs multiple functions when a certain condition is met.


Pre-conditions

The schedule you want the Scene to follow needs to be programmed.

Notes


User 99 will be reported for alarm system control events.

Programming Sequence



Instructions

1. Open Scenes.



2. Select Event Type and the Area.
3. Select the Schedule that will determine when this Scene is active.
4. Now program the sequence of actions that you want to happen.


Example

When Exit Delay 1 is running in the Office Area, set Camera 1 to start recording.

Programming Instructions for Outputs

Goal

Turn an output on or off according to an Action.



Pre-conditions

Program the Action and any associated components.


Notes

See Aritech Reliance XR Reference Guide for more details on Actions.

Write/Plan out on paper what you want to create. This makes it easier to set up Actions and associated settings.

Actions can be used without programming an Action Result. For example, outputs on Aritech Reliance XR are controlled by monitoring an Action State, no Action Result needs to be programmed.

Programming Sequence




Instructions

1. Select the Device that has the physical outputs you want to control.
2. Select Outputs.
3. Select Action.
4. Select the Schedule.

Combining Actions with Schedules

Schedules can control when a user has access, when an automatic Arm-Disarm occurs, when devices can be used, and more. Actions can turn Schedules on and off, making Schedules conditional based on when certain events occur.



The outcome is that we can control Users, Permissions, Areas, Zones, Actions, Arm-Disarm, Scenes, and Devices, based on various system conditions. This provides automation features that allows the system to respond in real-time to changing conditions.

This functionality is achieved by going to that Schedule and selecting Follow Action Number.

Take care when combining multiple schedules and actions as troubleshooting can get confusing. Always check and test functionality a single step at a time. Users and Zones can have multiple levels of permissions, be sure to check that each permission level is always appropriate.

Example

When a certain user is in the building, we can prevent an automatic Arm-Disarm from occurring.

First program an Action with the conditions you want and the Duration of the Action if necessary.

Next program Arm-Disarm with a User and Schedule.

Then set the Schedule to Follow Action Number.

When the action events are met, then the Schedule will become active and will be able to perform an Arm-Disarm at the appropriate time. If the conditions are not met, then the Arm-Disarm will never occur.

Arming and Disarming Your System

You may arm and disarm areas from a NXX-1820-keypad.

Only users with an authorized user code (Level 2 user) will be allowed to use the Aritech Reliance XR alarm system. Users with no valid user code (Level 1 user) do not have access as defined by EN 50131-3.


Lock Out On 3 Invalid Attempts

If an invalid PIN code is entered three times, the keypad will deny all log in attempts for 90 seconds. Attempts are counted from any method (e.g. keypad, app, or web page). You must wait the full 90 seconds before trying again with the correct PIN. This is to prevent brute-force attacks on guessing PIN codes.

Arm Your System In Away Mode

Enter a valid PIN code to unlock the screen.

Touch the Away or Away + button to arm your system in Away mode:



The icon will change to red when the alarm system is set in away mode.

If your system has multi-Area control enabled, the Away + button will be displayed.

A valid PIN code will need to be entered to determine what permissions they have; this includes which Areas and at what time/day that user has access.

Arm Your System In Stay Mode

Enter a valid PIN code with Stay permissions to unlock the screen.

Touch the Stay or Stay + button to arm your system in Stay mode:



The icon will change to yellow when alarm system is set in Stay mode.

If your system has multi-Area control enabled, the Stay + button will be displayed.

A valid PIN code will need to be entered to determine what permissions they have, this includes which Areas and at what time/day that user has access.

Arm Your System in Instant Stay Mode

Enter a valid PIN code with Stay permissions to unlock the screen.

To arm in Instant Stay mode, touch the Stay button **two** times until the icon is red and displays “Instant”:



This indicates the alarm system is set in Instant Stay Mode.

Arm Your System In Night Mode

Enter a valid PIN code with Stay permissions to unlock the screen.

To arm in Night Mode touch the Stay or Stay + button a total of **three** times until the icon is red and displays “Night Mode”:



Touching the Night Mode button again will cycle the system back to Stay Mode.

Disarm One Or More Areas

Touch the Off or Off + button to disarm your system:




If your system has multi-Area control enabled, the Off + button will be displayed.

A valid PIN code will need to be entered to determine what permissions they have, this includes which Areas and at what time/day that user has access.

Activate SOS Feature

Touch the SOS button to display the SOS feature:




On this screen touch and hold the appropriate button for 2 seconds to activate Manual Fire Alarm, Manual Auxiliary Alarm, or Manual Panic Alarm. These buttons can be enabled and disabled in the Area Options menu.

Depending on how your system is programmed, the control room may receive the corresponding event. Check with your control room to determine what action will be taken.

If silent alarm is enabled, then the keypad will not display any signs that the panic button was pressed.

To cancel a SOS alarm – return to the home screen, touch the Status button and turn the Area off.



Walk Test

1. Log in to panel web page.
2. Click Settings.
3. Click Walk Test.
4. Click Start.
5. Trigger each sensor by walking past PIRs, opening and closing reed switches, pressing tamper buttons, etc. Siren will chirp multiple times for each zone triggered.
6. Click Stop.
7. Click History.

User Reporting

When enabled, quick arming/disarming from the keypad without a PIN code will report user 98 to the Central Monitoring Station. SOS functions also report as user 98.

If the installer PIN is used to arm/disarm, user 256 is reported to the Central Monitoring Station. On legacy NX keypads user 255 will appear in event history.

Appendix 1: System Status Messages

Various messages may appear on the Status screen of Aritech Reliance XR Web Server and UltraSync+ app.

System

- AC power fail – The security system has lost its electricity power. May take up to 5 min to clear once power restored.
- Low battery – The security system's back up battery requires charging. May take up to 5 min to clear once battery charged.
- Battery test fail – The security system's back up battery requires changing. If after 48 hours this message does not clear, replace with a new battery. If the power fails, the system will not be operational.
- Box tamper – The security system's cabinet tamper input is open or either antenna is not connected.
- Siren trouble – The security system's external siren has a problem. Check the panel is securely installed on the wall.
- Over current – The security system is drawing too much current. Disconnect some hardwired inputs.
- Time and date loss – The security system time and date need resetting.
- Communication fault – The security system has detected a problem with the communication channel. Check the internet connection, Ethernet cable, or cellular reception is sufficient.
- Fire alarm – A fire alarm has been activated from the panel.
- Panic – A panic alarm has been activated from the panel.
- Auxiliary – An auxiliary alarm has been activated from the panel.

Area Number. Area Name

- Is on in the away mode – This Area is armed in the away mode.
- Is on in the stay mode – This Area is armed in the stay mode.
- Is ready – This Area is secure and ready to be armed.
- Is not ready – This Area is NOT ready to be armed, a zone is not secure.
- All Areas are on in the away mode – All Areas in this multi area system are armed in the away mode.
- All Areas are on in the stay mode – All Areas in this multi area system are armed in the stay mode.
- All Areas are ready – All Areas in this multi area system are secure and ready to be armed.

Zone Number. Zone Name

- In alarm – This zone has triggered a system alarm condition.
- Is bypassed – This zone is isolated (disabled) and will not activate an alarm.

- Chime is set – This zone is part of the chime group.
- Is not secure – This zone is not closed.
- Fire alarm – This zone has triggered a fire alarm.
- Tamper – This zone has triggered a tamper alarm.
- Trouble fault – This zone has an open circuit.
- Loss of wireless supervision – This zone is a wireless device and has lost its communication link with the control panel. Check the zone is within range of the panel and has sufficient battery.
- Low battery – This zone is a wireless device and needs a battery replacement.

Appendix 2: App and Web Error Messages

Various error messages may appear in the Aritech Reliance XR Web Server and UltraSync+ app.

Advanced/Settings Configuration Menus

- "You must select a Menu before you can scroll" – An attempt was made to scroll up or down from the top-level menu.
- "Select a submenu from the list or select back to access the main menu" – An attempt was made to scroll up or down from a submenu that has no additional levels.
- "Defaulting requires 2 levels" – a Shortcut was entered without two levels.

Read Write errors and results

- "Write Access Denied" – Changes cannot be saved; check you have permission or contact your installer.
- "Nothing displayed can be Saved" – No changes are possible on this screen.
- "Program Success!" – Changes have been saved.
- "Name Saved" – Changes have been saved.

Zones Page

- "No Zones Configured for Your Access" – Displayed on Zones page when there are no zones available to view

Data Entry Errors

- "Data must only contain the following characters"
- "Date must be of the form YYYY-MM-DD."
- "Day must be from 1 to 31"
- "Data entry must only contain the numbers 0–9 and A–F"
- "Data entry must only contain the numbers 0–9"
- "Data must be a number from X to Y"
- "Improper Time Value"
- "must be 4 to 8 digits"
- "You must enter a user Number between 1 and 1048575"
- "PIN digits must be between 0 and 9"
- "PIN Must be 4–8 digits from 0–9"
- "Data must not contain the following characters []"

Appendix 3: Advanced Menu Tree

1. **Users**
2. **System**
 1. System Clock
 2. General Options
 3. System Timers
 4. Siren Options
 5. Service and Test Options
 6. Status
 7. System Counts
 8. Language
 9. Automation Menu
3. **Zones**
 1. Zone Number
 2. Zone Name
 3. First Zone Profile
 1. Zone Type
 2. Zone Options
 3. Area Group
 4. Schedule Number
 5. User Number
 4. Second Zone Profile
4. **Areas**
 1. Area Number
 2. Area Name
 3. Area Entry-Exit Times
 4. Area Options
 5. Area Timers
 6. Area Type Settings
 7. Area Event Reporting
5. **Channels**
 1. Channel Number
 2. Channel Name
 3. Account Number
 4. Format
 5. Device Number
 6. Destination
 7. Next Channel
 8. Event List
 9. Attempts
 10. Language
6. **Communicator**
 1. General Options
 2. Auto Test
 3. IP Configuration
 1. IP Host Name
 2. IP Address
 3. Gateway
 4. Subnet
 5. Primary DNS
 6. Secondary DNS
 7. Ports
 8. Time Server
 9. IP Options
 4. Cellular Configuration
 1. SIM1 User Name
 2. SIM1 Password
 3. SIM1 APN
 4. SIM2 User Name
 5. SIM2 Password
 6. SIM2 APN
 5. Remote Access
 1. Panel Device Number
 2. Download Access Code
 3. Callback Server
 4. Download Options
 6. System Event Reporting
 1. System Channel
 2. Attempts
7. **Schedules**
 1. Schedule Number
 2. Schedule Name
 3. Follow Action Number
 4. Times and Days
8. **Actions**
 1. Action Number
 2. Action Name
 3. Function
 4. Duration Minutes
 5. Duration Seconds
 6. Event 1
 7. Event 2
 8. Event 3
 9. Event 4
 10. Result
9. **Arm-Disarm**
 1. Arm-Disarm Number
 2. Name
 3. User Number
 4. Schedule Number
10. **Devices**
 1. System Devices
 1. Control
 2. Keypad
 3. Zone Exp
 4. Output Exp
 5. Power Supply
 6. Reliance
 2. ARITECH Transmitters
 1. Transmitter Number
 2. Serial Number
 3. User
 4. Module Input
 5. Options
 6. Follow Action Number 1
 7. Signal Strength
 8. Sensor Application
 9. Follow Action Number
 3. Tablet Keypads
 1. Name
 2. Serial Number
 3. Area Group
 4. Keypad Options
11. **Permissions**
 1. Permission Number
 2. Permission Name
 3. Control Groups
 4. Permission Options
 5. User Timer Options
12. **Area Groups**
 1. Area Group Number
 2. Area Group Name
 3. Area List
13. **Menus**
 1. Menu Number
 2. Menu Name
 3. Menu Selections
14. **Holidays**
 1. Holiday Number
 2. Holiday Name
 3. Date Range
15. **Zone Types**
 1. Zone Type Number
 2. Zone Type Name
 3. Zone Type Armed
 4. Zone Type Disarmed
16. **Zone Options**
 1. Zone Options Number
 2. Zone Options Name
 3. Zone Options
 4. Zone Reporting
 5. Zone Contact Options
 6. Zone Report Event
17. **Event Lists**
 1. Event List Number
 2. Event List Name
 3. Event List
18. **Channel Groups**
 1. Channel Group Number
 2. Channel Group Name
 3. Channel List
19. **Action Groups**
 1. Action Group Number
 2. Action Group Name
 3. Action Group List
20. **Scenes**
 1. Scene Number
 2. Scene Name
 3. Activate Schedule
 4. Activate Event Type
 5. Activate Zone
 6. Scene Actions
21. **Cameras**
 1. Camera Number
 2. Camera Name
 3. LAN IP Address
 4. MAC Address
 5. Panel to Camera Connection
 6. When Doorbell Button is Pressed
 7. When Motion is Detected
22. **UltraSync**
 1. Web Access Passcode
 2. Ethernet Server 1
 3. Ethernet Server 2
 4. Ethernet Server 3
 5. Ethernet Server 4
 6. Wireless Server 1
 7. Wireless Server 2
 8. Wireless Server 3
 9. Wireless Server 4

Appendix 4: Troubleshooting

Connecting to the site with UltraSync+ app

If you have trouble connecting to your system using the app, here is a checklist:

- Check the serial number, web access passcode, user name and PIN codes match those in the Aritech Reliance XR.
- Web Access Passcode must not be 00000000.
- Web Access Passcode must be from 4 to 8 digits.
- User Name must be entered with a space between the first and last name and with correct capitalization.
- Check the User Name does not have an extra space at the end.
- If connected by Wired LAN, check the cable is plugged in and that the connection is working.
- Check Settings – Network – Enable UltraSync is ticked.
- Check that your mobile device has access to the internet (e.g. open a web browser).
- Power cycle connected equipment including Aritech Reliance XR and customer supplied router(s).

Viewing Cameras in UltraSync+ app

Check:

- Cameras must be added using UltraSync+ app “Add New Device” menu. This process will activate the camera once a secure password has been set. Manually adding a camera using the camera web page and panel web page (Menu – Settings – Cameras) is only possible AFTER the camera has been activated by the app.
- Camera has a good connection to the router. This is influenced by distance, barriers and walls, environmental conditions such as other routers and home appliances. When using the Aritech Reliance XR Router the nominal range is 10-30m.
- There is only one panel is on the same network. Each panel will periodically scan the network for cameras in the background and take ownership of all cameras found. If there is more than one panel on the same network, the cameras will swap panels and become unavailable when logging in to that panel.

Viewing Cameras on Touchscreen

If 7" WiFi Secondary Touchscreens are installed, check:

- Panel arming/disarming is possible. This confirms if the touchscreen is enrolled correctly with the panel and that the WiFi network is working.
- Cameras are accessible from the UltraSync+ app, the video preview and live stream should work. This confirms the camera is set up correctly, has access to the internet, and can be authenticated by the panel. For local only panels (no internet and no app), this step can be skipped.
- All cameras have a secure password.
- All touchscreens have the same password entered into the MENU – Touchscreen – Camera Username / Password.
- Reboot the WiFi router.