




Power Distribution Board

TS1044



Overview

The Tecom Power Distribution Board can be used to connect cables to the Challenger panel or Intelligent Access Controller, in a neat, compact manner.

There are six sets of terminals for RS-485 LAN and power, any one of which may be used to go back to the panel, with the other five going out to other LAN devices. This makes the Power Distribution Board ideal for star LAN configurations.

The Power Distribution Board has a Tecom 'B' board footprint for mounting in existing Tecom enclosures.

Features

- Supports all Tecom control panels
- 6 sets of terminals
- Keep wires in place, easily trace back to their source
- Compatible with existing Tecom enclosures

Power Distribution Board

Interlogix National Sales Enquiries 1300 361 479 Ground Floor 10 Ferntree Place Notting Hill, Victoria 3168 T: +61 3 239 1200 W: www.interlogix.com.au

Specifications

Supply voltage	9 to 14 VDC
Dimensions	50 mm x 79 mm
Data mode	Five sets of terminals for LAN and power
Operating temperature	0 to 70°C

Ordering information

TS1044	Power Distribution Board
--------	--------------------------